

CONTROLLER HC6500



Service Manual - SW 1.2X

679096-201 - Version 2.01

GB - 10.2008




Table of contents

Introduction to this Service Manual	4
Extended Menu for sw x.xx	5
CAN-BUS	11
General info/description	11
Fault finding options/results	12
Software and Communication	13
Software program for the controller	14
Communication cable	15
HC6500 software upgrade	18
Jobcom software upgrade	21
Software error codes	25
Controller error codes	25
Hardi HC Upgrade software error messages:	26
Dump of data from HC6500 Controller	27
Configuration of HC6500 to dump data	27
Dump data from HC6500	28
Configuration of HyperTerminal	30
Handling data from HyperTerminal	32
SafeTrack	34
General info/description	34
LookAhead	35
General info/description	35
Fault finding options/results	35
Pressure based regulation	36
General info/description	36
AutoFill	37
General info/description	37
Headland Assist	39
General info/description	39
Fault finding options/results	39
AutoWash	43
General info/description	43
Fault finding options/results	43
Wash program	44
TWIN	46
General info/description	46
AutoAgitation	47
General info/description	47
Fault finding options/results	47
PrimeFlow	48
General description of the electronic:	48
PrimeFlow basic setup	51
Test PrimeFlow setup	53
Programming a new SMCU	56
Reset a single SMCU	60



PrimeFlow fault finding; check first guide.....	63
Fault finding options and results	64
PrimeFlow alarms	66
Alarm 99, data cable weakness	66
Alarm 100 Low PrimeFlow voltage	69
Warning 101 PrimeFlow power cable defect	70
Warning 102 PrimeFlow computer defect	70
Checking SMCU and stepper motors.....	71
PrimeFlow Basic rules	71
Sensors.....	72
General info/description	72
Front angle sensor:	73
SafeTrack and Paralift angle sensor:	73
Slant angle sensor:	73
Flow sensor:	73
Pressure sensor:	74
Cable from Jobcom to tractor	76
General info/description	76
Revision	77

Introduction to this Service Manual

The primary aim of this manual is to help with fault finding. Each chapter is built up in the following template to offer the service person the quickest route to solving the problem:

- **Feature**
- **General info/description**
- **Sensors involved**
- **Constants involved**
- **Pinning/plugs/colors/codes**
- **Fault finding options/results**

Measurements Rules of thumb for HC 6500

This manual contains the most important information about HC 6500. In order to diagnose the system efficiently, remember the following rules of thumb.

1. Always check the feature functions correctly according to the Operators Instruction Book
 - **Does the boom rise when lift control button is activated upwards?**
 - **Does boom wing rise when tilt control button is activated upwards?**
 - **Does SafeTrack centre when centre button is activated?**
2. Check the sensors are correctly installed and that the signals correspond to check values.
3. Check that all constants are stored in the system and that the values correspond to the machine specifications.
4. Check the basic calibration values, e.g. speed by driving 3.6 km/h i.e. 1 m/s with the sprayer. Compare HC 6500 forward speed with tractor speedometer. Drive 100 meters. This should take 100 seconds.
5. Use the Guidance for HC 6500 setup chart as a reminder to set up all necessary menus.

Extended Menu for sw x.xx

To access Extended Menu, press and hold the "ESC" button, switch the power ON and wait until the menu is opened. The "[xxx]" indicates the choices or range. The factory default and helpful notes like increments of change are in italics.

This is how the main Extended Menu looks like on the controller display:

Extended Menu	
E1	Language Sprog Spracke Langue
E2	Unit Metric or US
E3	Reserved
E4	Data exchange COM port set up
E5	Optional sensors
E6	Service interval
E7	Total register Master reset
E8	Settings Liquid sys Hydraulic
E9	Twin actuator setup
English Dansk Deutsh Francais	
Svenska Cestina Nederlandse Polski	

- **E1: Is the language choice. Note: For Russian, the HC6500 hardware version with Cyrillic text is used.**
- **E2: Is for what unit the controller shall use.**
- **E3: Reserved**
- **E4: Setup of the data communication.**
- **E5: Setup of optional sensors. It is typically the pressure, fan revolutions and tank contents (TankGauge).**
- **E6: Setup of the service interval.**
- **E7: Setup of factory settings.**
- **E8: Settings of the regulation, tank, track and misc. setting are**
- **E9: Is for setup of the TWIN actuators.**

E1 Language	E1.1 English <i>(Default)</i>
	E1.2 Dansk <i>(Danish)</i>
	E1.3 Deutsch <i>(German)</i>
	E1.4 Francais <i>(French)</i>
	E1.5 Svenska <i>(Swedish)</i>
	E1.6 Cestina <i>(Czech)</i>
	E1.7 Nederlandse <i>(Dutch)</i>
	E1.8 Polski <i>(Polish)</i>

E2 Unit	E2.1 Metric units <i>(default)</i>
	E2.2 US units

E3 Reserved

E4 Data exchange	E4.1 COM1 Setup	E4.1.1 Equipment type	E4.1.1.1 Printer <i>Select if using a 12 volt printer</i>
			E4.1.1.1 Dump <i>Select if you want to dump data to a PC</i>
			E4.1.1.1 Printer & Dump <i>Select if you want to print to a 12 volt printer and data dump from the same COM</i>
		E4.1.2 Baud rate	E4.1.2.1 9600 baud <i>(Default)</i> <i>Fastest Baud rate. Select 9600 for HARDI 12V printer</i>
			E4.1.2.2 4800 baud <i>Fast Baud rate</i>
			E4.1.2.3 2400 baud <i>Medium speed Baud rate</i>
	E4.1.2.4 1200 baud <i>Slowest Baud rate</i>		
	E4.1.3 Protocol select	E4.1.3.1 HARDI VRA protocol	
	E4.2 COM2 Setup	E4.2.1 Equipment type	E4.2.1.1 Printer <i>Select if using a 12 volt printer</i>
			E4.2.1.1 Dump <i>Select if you want to dump data to a PC</i>
			E4.2.1.1 Printer & Dump <i>Select if you want to print to a 12 volt printer and data dump from the same COM</i>
		E4.2.2 Baud rate	E4.2.2.1 9600 baud <i>(Default)</i> <i>Fastest Baud rate. Select 9600 for HARDI 12V printer</i>
E4.2.2.2 4800 baud <i>Fast Baud rate</i>			
E4.2.2.3 2400 baud <i>Medium speed Baud rate</i>			
E4.2.2.4 1200 baud <i>Slowest Baud rate</i>			
E4.2.3 Protocol select	E4.2.3.1 HARDI VRA protocol		



E5 Optional sensor	E5.01 Pressure	E5.1.1 Minimum [-99.9 to 99.9]			
	Connected to section valve PCB	Default is 0,0 Bar. Key in pressure making sensor output 4mA. See sensor for min. value.			
		E5.1.2 Maximum [0 to 999.9]			
		Default is 10.0 Bar Key in pressure making sensor output 20mA. See sensor spec. for max. value.			
	E5.02 Fan speed	E5.2.1 PPU [0 to 999999]			
	Connected to section valve PCB	Key in pulses per revolution. set to 1 if one puls is given per revolution			
	E5.03 Tank contents	E5.3.1 Sensor Type	E5.3.1.1 Not present		
			E5.3.1.2 Reserved		
			E5.3.1.3 Reserved		
			E5.3.1.4 HARDI Tank gauge		
		E5.3.2 Reserved			
	E5.04 Wind speed	E5.4.1 Not used			
			Value	Unit	Default
	E5.05 Wind direction	E5.5.1 min	0	min	0
		E5.5.2 max	359	max	359
	E5.06 Air temperature	E5.6.1 min	-20	min	-20
		E5.6.2 max	70	max	70
	E5.07 Relative humid	E5.7.1 min	0	min	0
		E5.7.2 max	100	max	100
	E5.08 RPM sensor	PPU	1	PPU	1
	E5.09 Extra 1	E5.9.1 PPU	1	PPU	1
		E5.9.2 Extra1 name			
		E5.9.3 Extra1 unit			
	E5.10 Extra 2	E5.10.1 PPU	1	PPU	1
		E5.10.2 Extra2 name			
		E5.10.3 Extra2 unit			
	E5.11 Extra 3	E5.11.1 3A Min	0	Volt	0
		E5.11.2 3A Max	5	Volt	5
		E5.11.3 Extra3 name			
		E5.11.4 Extra3 unit			
	E5.12 Extra 4	E5.12.1 3A Min	0	Volt	0
		E5.12.2 3A Max	5	Volt	5
		E5.12.3 Extra4 name			
		E5.12.4 Extra4 unit			

E6 Service Interval	E6.1.1 Check filters	A hours	10 hours
PIN = 04711	E6.1.2 Grease boom	B hours	50 hours
	E6.1.3 Grease track and centre	C hours	250 hours
	E6.1.4 Miscellaneous service	D hours	Hours are not defined
	E6.1.5 Check nozzles	Nozzle	50 hours

E7 Factory settings	E7.1 Total register	E7.1.1 Register 0. Shows start & stop dates & time
	E7.2 Master reset	Reset all values except for Register 0 in HC6500 and JobCom PIN = 12345

E8 Settings	E8.1 Regulation	E8.1.1 Min. duty cycle	[2%] Minimum and default is 2%. Increase value if motor hesitates to turn. For LookAhead, set to 5% +/- 1%.
		E8.1.2 Min speed	[0.5Km/t] Minimum speed required before regulation valve will operate. Default is 0.5 Km/h.
		E8.1.3 Min. pressure	[0.0 Bar] Default is 0.0 Bar. At 0.0 Bar, feature is disabled. Pressure transducer needed. If pressure drops below the set value, the pressure regulation will stop.
		E8.1.4 Reserved	
		E8.1.5 LookAhead	[Disabled/Enabled] Default = No. Regulation valve must have position feedback transducer and Boom sensor must be fitted.
		E8.1.6 LookAhead Regulation delay	[0 to 9 Sec.] Default = 3 seconds. This is time the regulation valve waits before starting. Delay allows fluid system to stabilise before regulation valve starts operation. For few boom sections and or big liquid flow, 3 s is recommended. For many boom sections and or small liquid flow, 1 or 2 s is recommended.
		E8.1.7 Sensors	E8.1.7.11 Pressure sensor: passive Default passive. If installed only pressure will be shown in display, no regulation E8.1.7.12 Pressure sensor: active Select if pressure regulation should be active
	E8.2	E8.2.1 Tank size	[L] Enter true tank size. Used by AutoFill and AutoAgitation
		E8.2.2 Reserved	
		E8.2.3 Data points	Calibration values for HARDI TankGauge Read out of: Data point number, measured water level and recorded volume.
	E8.3 Reserved		
	E8.4 Track	E8.4.01 Enable	[Disable/Enable] To enable SafeTrack function.
		E8.4.02 Reserved	
		E8.4.03 Chassis	[None, CM05 S, CM05 M, CM05 L] Default is CM05 M For CM: Use S for 3200, M for 4400, L for 6600.
		E8.4.04 Sprayer draw bar	[0-200 cm] Default for CM: 101 cm Length from draw bar pin hole to front anchor bolt for draw bar.
		E8.4.05 Manual angling	[-9% to 9%] Default is 0. Sets the manual steering speed. Note + and - can be changed by toggling. Use steps of 10% as a guide.
		E8.4.06 Boom fold sensor	[1,2] Default: 1. This is the number of boom fold sensors present.
E8.4.07 Error print		[Yes] Prints last 3 hazardous situations and shows Alteration log changes.	
E8.4.08 Minimum radius		[6,0m] Minimum turning radius allowed for the trailer. Tank size 3200 L= 6.5, 4400 L= 7.0, 6600 L= 9.0. Increase to be able to make sharp corner at headland without SafeTrack	
E8.4.09 Max speed when turning		[Km/t] Default 18km/t. Above set speed, no angling is possible.	
E8.4.10 Safety factor		[100%] Raising this value increases captiousness. Default is 100% for a CM 4400. For CM 3200, use 90%. For CM 6600, use 120%. Use steps of 10% as a guide to changes.	



E8 Settings	E8.5 Misc.	E8.5.1 Foot switch	[Disable, On/Off level, On/Off pulse] For remote On/Off of main switch, it allows the use of other switch system
		E8.5.2 Rate deviation	[Step size: xx%] Default is 10%. Can be altered. If set at 0%, this allows 3 rates to be set up in menu 1.1
		E8.5.3 Capacity left	[Distance, Area] Affects readout from Display icon. Will show distance or area remaining
		E8.5.4 AB switches setup	E8.5.4.1 AB switches disable E8.5.4.2 Valve or lamp E8.5.4.3 Hydraulics DAH E8.5.4.4 Hydraulics Delta DH
		E8.5.5 Foam marker	Setup when sprayer has foam marker. Also setup menu 2.2.2
		E8.5.6 Startup picture	Select desired startup picture
		E8.6 Sprayer type Liquid, boom	E8.6.1 Liquid system
		E8.6.2 Dual Line	E8.6.2.1 Dual Line system type 2 sets of boom tubes and valves. Only EVC E8.6.2.2 Sensor type line change Pressure or speed based sensor E8.6.2.3 System lag Time lag to prevent osc. between the 2 spray lines E8.6.2.4 Line overlap Time the spraying overlaps so the liquid system stabilizes
		E8.6.3 Boom fold hydr.	E8.6.3.1 Force m. HPZ, HAZ E8.6.3.2 Force m. FTZ E8.6.3.3 Delta m. LPZ E8.6.3.4 Eagle m. SPC E8.6.3.5 Alpha GVA E8.6.3.6 TWIN Force 32-36m
		E8.6.4 PrimeFlow setup	E8.6.4.1 Test Nozzle positions Each nozzle is closed for 2 sec. Check that sequence does not jump E8.6.4.2 Assign nozzle position to SMCU Assign nozzle position after replacement. Confirm nozzle position after master reset. E8.6.4.3 Reset nozzle position in SMCU Reset all connected SMCU's to prepare for assignment of new nozzle type E8.6.4.4 Force to 2 motor SMCU For service a 3 motor SMCU can be forced to be a 2 motor drive E8.6.4.5 Reserved E8.6.4.6 Change Nozzle order Key in SMCU number for change of nozzle order at brackets



E8 Settings	E8.6 Sprayer type Liquid, boom	E8.6.5 AutoWash and AutoFill setup	E8.6.5.1 Select AutoWash and Fill options	E8.6.5.1.1 None <i>Nothing installed</i> E8.6.5.1.2 AutoWash installed <i>Select if AutoWash installed</i> E8.6.5.1.3 AutoWash/Fill inst. <i>Select if AutoWash/Fill installed</i> E8.6.5.1.4 AutoFill installed <i>Select if AutoFill installed</i>
			E8.6.5.2 Pump setup	E8.6.5.2.1 NCM 3200/4400 <i>AutoWash is automatic SuctionValve standard direction</i> E8.6.5.2.2 NCM6600 single pump <i>AutoWash is automatic SuctionValve rotated 180grd</i> E8.6.5.2.3 NCM6600 double pump <i>AutoWash prompts for start and stop on tractor hydraulic lever</i> E8.6.5.2.4 NCM9000 double pump <i>AutoWash prompts for start stop on tractor hydraulic lever</i> E8.6.5.2.5 Hardi Alpha 2500 3000 <i>SuctionValve and PressureValve is turned 90 degrees</i> E8.6.5.2.5 Hardi Alpha 3500 4100 <i>SuctionValve and PressureValve is turned 90 degrees</i>
			E8.6.5.3 AutoAgitation setup	E8.6.5.3.1 Tank level for full to half <i>Key in tank level% for shift from full tank to half tank</i> E8.6.5.3.2 Tank level half to empty <i>Key in tank level% for shift from half tank to almost empty tank</i> E8.6.5.3.3 Powerful agitn full tank <i>Adapt to risk of sedimentation but no risk of foaming</i> E8.6.5.3.4 Powerful agitn half tank <i>Adapt to small risk of sedimentation, some risk of foaming</i> E8.6.5.3.5 Soft agitation full tank <i>Some agitation needed, no risk of foaming</i> E8.6.5.3.6 Soft agitation half tank <i>Adapt to risk of foaming. Ensure a little agitation</i>
				E8.6.5.4 AutoWash print report <i>Prints timestamps and water amounts transferred in each step. Select print report from 1 to 8.</i>
				E8.6.5.5 Register for AutoWash <i>Key in register no. If 0, wash is added to actual spraying register.</i>

E9 TWIN Actuator	E9.1 Fan speed Air angle	E9.1.1 Fan speed setup	E9.1.1.1 Fan speed forward <i>Select forward for trailed sprayers</i> E9.1.1.2 Fan speed reverse <i>Select reverse for ALPHA sprayers</i>
		E9.1.2 Air angle setup	E9.1.2.1 Air angle forward <i>Select forward for trailed sprayers</i> E9.1.2.2 Air angle revers <i>Select reverse for ALPHA sprayers</i>
		E9.1.3 Select TWIN actuator Type	E9.1.3.1 TWIN actuator Linak <i>Select TWIN actuator type Linak</i> E9.1.3.2 TWIN actuator new <i>Not available</i>

Fault finding options/results

E = Error

P = When programming

Name	LED code	Explanation	
Power off CPU crashed	LED off	CPU crashed when LED was turned off	E
CPU crashed	LED on	CPU crashed (when LED was turned on), loosing control over LED No LED reaction on key press	E
CPU is ok No key is pressed	LED on	Connection to CAN is ok	E
Key is pressed	LED on, except off for 0.2 sec	Confirm that key press is read by CPU	E
CAN bus short circuit	1 blink code	Short circuits of cables: CANH or CANL connected to ground, 5Volt or 12Volt Detected by CAN transceiver Blink code is sent continuously	E
CAN bus open circuit	2 blink code	CAN controller Busoff error. Mostly due to no other computer on CANbus Blink code is sent continuously	E
JobCom not connected	3 blink code	No contact to JobCom. Receives no alive telegrams from JobCom Blink code is sent continuously. This code is disabled for JobCom	E
Data missing	4 blink code	Data (expected/subscribed) from other computer is not received. Other computer is Busoff or disconnected. Blink code is sent once. This code is disabled for SetBox, Grip, FluidBox	E
Ready for SW upload	5 blink code	Ready for software upload. Activated by Pin 17 BootLoadEnable Blink code is sent continuously	P
Terminal not connected	6 blink code	No contact to terminal. Receives no alive telegrams from terminal Blink code is sent continuously. This code is disabled for terminal	E
Received data is invalid	7 blink code	Computer software versions are incompatible, data sent from other computer cannot be used by this computer. Blink code is sent once per invalid data. This code is disabled for SetBox, Grip, FluidBox	E
SW upload successful	8 blink code	SW upload successful. Blink code is sent continuously	P
Watchdog reset	9 blink code	Watchdog reset. Note the watchdog is the CPU monitoring that all tasks are run. The watchdog does not detect when the CPU crashes. Blink code is sent once	E
Cannot logon	10 blink code	Cannot logon. CANbus address claimed by other computer Blink code is sent continuously	P
Loading software	Fast blinking 10Hz	Loading software. Blink code is sent continuously	P

LED on Jobcom

JobCom for LED	New HC6500 Green D27	New HC6500 Red D28
	While starting	Version no, integer part
While operating	0.5Hz	As for terminal
Ready for SW upload	Off	5 blink code
Loading software	Off	Fast (10Hz)
SW upload successful	Off	8 blink code

Measurements

The Blue CAN On/Off turns the units on when it is high (>2.0V) and off when it is low (<1.0V)

Software and Communication

The software in the HC6500 and Jobcom can be upgraded. Examples for this are improvements for better performance and bug fixes.

When the software for the controller is changed, it will be available from Hardi's Technical Service department. The software can be sent as an attached Zipped file on the E-mail.

HC6500 Upgrade:

An update of the HC6500 will erase the settings saved in the HC6500 Controller, e.g. display and port settings.

JobCom Upgrade:

If the software of the JobCom is 1.15 and the new upgrade software is higher than 1.30, the settings in the JobCom will remain in the memory of the JobCom.

If the JobCom software is lower than 1.15 all settings are erased and all parameters have to be setup again manually. After an update of the JobCom it needs up to 60 sec. to reset itself. The reset is performed after the first power up of the JobCom. It is not possible to see on the JobCom when it is resetting or when it is finished.

If the HC6500 is powered up in normal mode it will show alarm 110, "Warning JobCom resetting" when the JobCom is resetting, when it is finished alarm 111, "Alarm Switch HC6500 OFF & ON" will appear.

NOTE: Do not power up the HC6500 in Extended menu first time after a software update, the alarm will not appear in extended menu and all setting done when the JobCom is resetting will be erased during the reset.

Use following codes to reset the system:

Code	Function
89898	Store a backup of the current configuration
88888	Recall backup of configuration stored with 89898
12345	Resetting all parameters except register 0 and the backup configuration stored with code 89898
74650	Resetting all parameters to defaults

It is recommend strictly to follow these update sequences when updating the JobCom and HC6500:

A: Keep everything as is:

1. Update the JobCom.
2. Update the HC6500 Controller.
3. Setup the HC6500.
4. Test all functions of the HC6500, JobCom and sprayer.
5. Store the configuration in the JobCom. Enter code 89898.

B: Keep current setup and register 0, reset user registers and alarm log files:

1. Update the JobCom.
2. Update the HC6500 Controller.
3. Setup the HC6500.
4. Store the configuration in the JobCom. Enter code 89898.
5. Reset register and alarm log files. Enter code 12345.
6. Recall the configuration in the JobCom. Enter code 88888.
7. Test all functions of the HC6500, JobCom and sprayer.

C: Programming a new HC6500 and a new JobCom:

1. Update the JobCom.
2. Update the HC6500 Controller.
3. Setup the HC6500 and JobCom.
4. Store the configuration in the JobCom. Enter code 89898.
5. Reset register and alarm log files. Enter code 12345.
6. Recall the configuration in the JobCom. Enter code 88888.
7. Test all functions of the HC6500, JobCom and sprayer.

Read the chapters "JobCom software upgrade" and "HC6500 software upgrade" for a detail description of how to perform the updates.

Software program for the controller

The software sent in a mail as Zip file.




The Zip file must be unpacked and put into a folder.

The top file (HardiExeUploadWinvxxx.exe) is the upgrade program.
The two other files (xxx.bin) are the software for the controller and the Jobcom.

This example show HC5500 software file "HardiV316.bin" with software version is 3.16.


The Jobcom reads "HardiJCV1.11.bin" with software version 1.11.

Note: *It is very important that these three files are in the same folder at all time otherwise will the upgrade program not work.*



When the program is activated, a dialogue box will appear on the PC.
In the dialogue box, the software version for both the controller and the Jobcom can be seen before the software is uploaded.

How to use the Hardi upgrade program is described in section "Software upload HC6500" and "Software upload Jobcom".



- A:** Information about the current version of Hardi HC Upgrade and the software in the connected controllers.
- B:** Here you do a complete serial port scan.
- C:** Shows the software available in current folder on the PC: HC5500 3.25, HC6500 1.02 and JobCom 1.26
- D:** Here you select the PC comport to use.
- E:** Only for production purposes.
- F:** Start upgrade.
- G:** Exit program.


Information from the Info button in step A:




Communication cable

The connection from the PC to the controller is made with HARDI cable P/N 72271600. The cable has a short circuit in one of the connector, normally where the label is. For software update this means HC6500.


- A: 12VDC from tractor
- B: HARDI SprayBox
- C: HARDI Controller
- D: HARDI cable connected to COM 1 on Controller
- E: Computer, cable connected to COM or USB port



HARDI cable, P/N72271600, connections
Loop in communication cable pin 5 and 9.



The cable is marked with "Hardware halt" at the end with the loop. The mark is on the cable or with a yellow sticker on the connector. If the cable is turned the wrong way, the software upgrade is not possible.



The communication cable is shown on the spare part CD, pages M302. Part number for the cable is 72271600 and can be ordered as a normal spare part.

USB to RS232 Converter

If there is no RS232 port, or problems with the Com port on the computer, use a converter from USB to RS232. The systems requirement to use a converter is:
A computer with Windows XP or later.
USB to RS232 serial converter, Hardi P/N 26025900.
Serial NULL-modem cable, or Hardi "Communication cable" P/N 72271600.




Install the USB to RS232 serial converter using the instructions and driver, which should be included with the USB to RS232 serial converter.


NOTE:
Do not plug the USB-RS232 converter into the system before the driver is finished installing



Insert the CD-Rom with the driver in the drive.
Select "Search for the best driver in these locations" and "Search removable media floppy, CD-ROM" and select Next>



At this screen select "Next>"



Accept the "Information" window by pushing the "Next>" button



Select restart the computer now.
Push the "Finish" button. After a restart of the computer the adaptor is ready to use.



Verify comport number.
Before you can start upgrading your Hardi controller, you need to find the number of the USB-serial Converter.
Click on the Windows "start" button and select "Control panel".



Double-click on the "System" icon.



Click on the "Hardware" tab.

Click on the "Device manager" button




Find and expand the "Ports" icon by clicking on the '+' left to the icon. Now you will see a screen not so different from the picture above. Here you see that there are many devices using a COM number, This may varies from PC to PC.

In this case it is COM7.

But keep in mind, that this is just a guide, you need to see your self, what number your "Serial On USB Port" has been installed on.

With this number in mind you can close the Device Manager window, and continue to next step.



HC6500 software upgrade

Enter menu 4.8.2 to see the current software version in the controller

If the software version of the JobCom is 1.15, 1.30 or higher prior to the upgrade is it possible to save and recall the current configuration of the JobCom after the update.

In menu E7 Enter code 89898 to save the configuration and code 88888 to recall the configuration.

The HC6500 display and port settings will not be saved.

It is always a good procedure to print or save the system configuration before a software upgrade, see chapter "Dump of data from HC6500 Controller" how to dump the configuration to the PC.

The communication cable without the "Hardware halt" is plugged into the PC.

This is done before the computer is powered up.

The communication cable with the "Hardware Halt" is plugged into the HC6500 in COM 1 (A) port.

Power ON the PC

Power ON the HC6500

The HC6500 beeps 3 times at start-up to indicate it is ready to upgrade. In addition, the red LED continues to flash 5 times and then pause. The screen will stay black during upgrade.

The controller awaits contact to the Hardi HC6500 upgrade software programme.

On the PC, the upgrading program can be started up and the PC dialogue box should look like this.

The dialogue box shows what software version will be uploaded to the HC6500 Controller.

Communication port has to be chosen.



If you use a USB-Serial converter see section "USB to RS232 Converter" how to find the Com port number.

Select "Connect".


High-speed (CP2102) can only be used with the HC6500 Controller.

4.8.2 Software versions all computer		
	Version	
Terminal HC 6500	1.13	Version
JobCom HC 6100	1.15	
Grip HC 6300	0.00	
SetBox HC 6400	0.00	
FluidBox HC 6200	0.00	

Computer detail screens show details in case of faults




If there are problems with the connection the upgrading program will tell what kind of error there is and what can be done to solve the problem.



When you press "Connect" the upgrade begins, after a little while, you will be prompted with a window.

There are two versions of this window; one where you have to upload a new boot and a new application. This looks like the window to the right.



The only difference between the two versions is the "Upload new boot..." line. This is because it isn't always necessary to upload a new boot, to upload new application software.

- Click "OK" to upgrade HC6500.
- If HC6500 needs to upgrade boot software it will erase the old one, and the "Hardi HC Upgrade" will upload a new version.
- If it was necessary to upgrade the boot software (if not, skip this step), you will be prompted with the following window after the boot upload.






- Turn off and on the power on HC6500 and wait until HC6500 have beeped 3 times and the red LED continues to flash 5 times and then pause. Then click "OK" to continue upgrading HC6500.
- Afterwards "Hardi HC Upgrade" will erase the current application on HC6500 and upload the new one.


The upgrade takes about 5-10 minute.

WARNING:

Do not power down the PC during the upgrade.



- At last "Hardi HC Upgrade" will prompt: "Upload of HC6500 SW X.XX was successful!".



Read first page in this chapter "Software and Communication" to decide if or which reset/recall code should be used to complete the upgrade of the HC6500.

WARNING:

Code 74650 will erase all settings in the HC6500 Controller and the JobCom, also the stored backup saved with code 89898.

E7 Total register Master reset	
E7.1	Total register
» E7.2	Factory default/Master reset
Two PIN possibilities. One for factory default setting and the other for master	

Jobcom software upgrade

Enter menu 4.8.2 to see the current software version in the JobCom.

If the software version of the JobCom is 1.15, 1.30 or higher prior to the upgrade is it possible to save and recall the current configuration of the JobCom after the upgrade.

In menu E7 enter code 89898 to save the configuration and code 88888 to recall the configuration.

The HC6500 display and port settings will not be saved.

It is always a good procedure to print or save the system configuration before a software upgrade, see chapter "Dump of data from HC6500 Controller" how to dump the configuration to the PC.

The communication cable without the "Hardware halt" is plugged into the PC.

This is done before the computer is powered up.


4.8.2 Software versions all computer		
	Version	
Terminal HC 6500	1.13	Version
JobCom HC 6100	1.15	
Grip HC 6300	0.00	
SetBox HC 6400	0.00	
FluidBox HC 6200	0.00	

Computer detail screens show details in case of faults



The communication cable with the "Hardware Halt" is plugged into the JobCom.

The communication cable is plugged into the Jobcom before it is switched on.



Power ON the PC

Power ON the JobCom on Spray box.

To be sure that JobCom is ready to be upgraded, ensure that the red LED flashes 5 times and then pause in a loop.

Here you notice the circle which surrounds the red LED on the JobCom.




On the PC, the upgrading program can be started up and the PC dialogue box should look like this.

The dialogue box shows what software version will be uploaded to the Job-Com.

Communication port has to be chosen.


If you use a USB-Serial converter see section "USB to RS232 Converter" how to find the Com port number.

Select "Connect".



If the upgrade program does not find a connection between the Jobcom and PC, this error message will appear.

If this message appears, then see if the cable is attached correctly and there is power on the controller. If this does not help, power down the PC and the controller and start all over.



When you press "Connect" the upgrade begins, after a little while, you will be prompted with a window. There are two versions of this window, one where you have to upload a new boot and a new application. This looks like the window to the right.



The only difference between the two versions is the "Upload new boot..." line. This is because it isn't always necessary to upload a new boot, to upload new application software.


- Click "OK" to upgrade JobCom.
- If JobCom needs to upgrade boot software it will erase the old one, and the "Hardi HC Upgrade" will upload a new version.
- If it was necessary to upgrade the boot software (if not, skip this step), you will be prompted with the following window after the boot upload:




- Turn off and on the power on JobCom and wait until JobCom red LED continues to flash 5 times and then pause in a loop. Then click "OK" to continue upgrading JobCom.

- Afterwards "Hardi HC Upgrade" will erase the current application on JobCom and upload the new one.

The bottom bar of the display dialogue box indicates the upload progress.




When the upload of the new software has started, diode N28 and D27 will start to flash together with the watchdog.



- At last "Hardi HC Upgrade" will prompt: "Upload of JobCom SW X.XX was successful!" and you are done.

If the updating was not successful, try again.
Check the power supply to sprayer and PC.



Read first page in this chapter "Software and Communication" to decide if or which reset/recall code should be used to complete the upgrade of the JobCom.

WARNING:

Code 74650 will erase all settings in the HC6500 Controller and the JobCom, also the stored backup saved with code 89898.

E7 Total register Master reset	
E7.1	Total register
» E7.2	Factory default/Master reset
Two PIN possibilities. One for factory default setting and the other for master	

Software error codes

Controller error codes

Error codes can be a combination of the below:

E.g. Code 6040: This is a combination of code 6000 and code 40 where 6000 means it could not write to the serial port and 40 means a reply is missing.

Codes indicating the uploader program has gone into a non-existence mode:

555
666
777
888
999

Codes for Send Data () errors:

1000 Serial port is not open
2000 Could not write to serial port (API-call WriteFile() failure)

Codes for GetData() error:

5000 Serial port is not open
6000 Could not write to serial port (API-call WriteFile() failure)
7000 Number of bytes read from serial port was less than expected
8000 Checksum fault in the received data

Codes for UploadMain() error:

3 H8 Flash could not be erased
10 Could not send 'SN' or 'MR' or 'PM' to the controller
20 No answer from controller on 'SN' or 'MR' commando
1..9 Controller answered 'SNx', 'MRx' or 'PMx' where x = 1..9 (0 expected)
30 Reply from controller not recognized (SN0 or MR0 expected)
40 Could not read the reply from 'PM' from the serial port

Codes for SendProgram() errors:

100 Unknown controller type (HC5500 or JobCom)
200 Could not write a data-block to serial port
300 Answer from the controller not recognized as block acknowledge
400 Negative block acknowledge from the controller
500 Could not read block acknowledge from serial port
600 Could not send BLKEND to controller
700 Could not read answer on BLKEND from serial port
800 Controller gave illegal answer on BLKEND

Codes for SendProgramExternalFile() errors:

10000 Program file is too small
20000 Unknown controller type (HC5500 or JobCom)
30000 Could not write data-block to serial port
40000 Could not read block acknowledge from serial port
50000 Answer from the controller not recognized as block acknowledge
60000 Negative block acknowledge from the controller
70000 Could not send BLKEND to controller
80000 Could not read answer on BLKEND from serial port
90000 Controller gave illegal answer on BLKEND

Hardi HC Upgrade software error messages:

Message	Possible Error	Solution
Please select a Comport	Didn't select a Comport	See section "Software program for the controller"
No Hardi Unit found on ComX (Xbeing the selected comport number).	A: Didn't select correct comport, which is connected to Hardi Unit. B: No power on unit. C: Comport already in use.	A: See section "Software program for the controller" B: Make sure the device power cable is correctly installed. C: Make sure that the comport selected, isn't already in use by another program, in that case, close the other program.
Upload of main program failed, error code (20)	Forgot to turn off the HC6500/JobCom after boot Upload	HC6500: See section "HC6500 software upgrade". JobCom: See section "JobCom software upgrade".
Upload of main program failed, error code (2)	No software to upload found	See section "Software program for the controller".

Dump of data from HC6500 Controller

Configuration of HC6500 to dump data

Open the extended menu in the controller by doing following:

- Switch OFF the Controller
- Push and hold the "ESC" button on the Controller
- Switch ON the Controller and release the "ESC" when the start up picture has disappeared



Select:
E.4 Data exchange COM port set up

Extended menu	
E1	Language Sprog Sprache Langue
E2	Unit Metric or US
E3	Reserved
» E4	Data exchange COM port set up
E5	Optional sensors
E6	Service interval
E7	Total register Master reset
E8	Settings
E9	TWIN actuator setup
Setup of RS232 COM 1,2 Equipment, baud rate, protocol	

Select:
E4.1 COM 1 setup

E4 Data exchange COM port set up	
» E4.1	COM 1 setup
E4.2	COM 2 setup
Setup communication for VRA/remote, printer, dump, print dump	

Select:
E4.1.1 Equipment type

E4.1 COM 1 Setup	
» E4.1.1	Equipment type
E4.1.2	Baud rate
E4.1.3	Protocol select
Choices are VRA/remote, printer, dump, Print dump	

Select:
E4.1.1.3 Print & Dump

Push "ESC" to return to previous menu

E4.1.1 Equipment type	
E4.1.1.1	Printer
E4.1.1.2	Dump
o » E4.1.1.3	Printer & Dump
E4.1.1.4	VRA / remote
Select if you want to print to a 12 volt printer and data dump from the same COM	



Select:
E4.1.2 Baud rate

E4.1 COM 1 Setup	
E4.1.1	Equipment type
» E4.1.2	Baud rate
E4.1.3	Protocol select
Choices are VRA/remote, printer, dump, Print dump	

Select:
E4.1.2.1 9600 baud

E4.1.2 Baud rate	
o » E4.1.2.1	9600 baud
E4.1.2.2	4800 baud
E4.1.2.3	2400 baud
E4.1.2.4	1200 baud
Fastest Baud rate	

Leave the extended menu by switching off the controller

Dump data from HC6500

Switch on the controller and open the normal menu by pushing the Menu button

Select:
5 Logbook

Main menu	
1	Daily settings
2	Setup
3	Calibration
4	Toolbox
» 5	Logbook
Data records of registers or configuration for print or dump	

Select:
5.1 Print

5 Logbook	
» 5.1	print
5.2	Data dump
Register and configuration can be printed to the 12 volt printer	

Select one of following options:
5.1.1 Print single register
5.1.2 Print all registers
5.1.3 Print configuration
5.1.4 Print PrimeFlow status

5 Logbook	
» 5.1	print
5.2	Data dump
Register and configuration can be printed to the 12 volt printer	

Push the Enter button to select which type of dump is desired. The data can be read in Hyper terminal



Select:
5.2 Data dump

5 Logbook	
5.1	print
» 5.2	Data dump
Register and configuration can be dumped to a PC via e.g. Hyper Terminal	

Select one of following options:
5.2.1 Data dump of raw data
5.2.2 Hyper terminal service report

Push the Enter button to select which type of dump is desired. The data can be read in Hyper terminal

5.2 Data dump	
» 5.2.1	Data dump of raw data
5.2.2	Hyper terminal service report
Transmit data from all 99 registers in comma-separated file for Excel	

Configuration of HyperTerminal

It is possible to transmit and receive data to and from the HC5500/6500 through the com port on the controller and the computer.

Use HyperTerminal on the PC to transmit or receive data from the Controller.

The connection from the PC to the controller is made with HARDI cable P/N 72271600. The cable has a short circuit in one of the connector, normally where the label, "Hardware halt" is. This connector should be connected to the PC when transferring data.

The data read in HyperTerminal can be exported to a spreadsheet or a word processing, see section "Handling the data".

Configuration of the HyperTerminal:

Baud rate 9600

Data bit 8


Parity None

Stop bit 1

Flow control Hardware

Emulation ANSI

The HyperTerminal is normally installed in the "Start" menu in Windows:




Open HyperTerminal and enter a name



Select COM1 or another available COM port on the PC




Add the port setting data and select "Apply" and "OK".



To set up the Emulation in HyperTerminal select in the File menu:

Properties and then Settings



Select OK in this warning window.



Select "Delimited" as data type in the next window.




Mark "Other:" with an "|" (press AltGr+|).



Select "Finish"



And Excel will open the file:



SafeTrack

General info/description

SafeTrack can be set to a minimum radius which activates "soft stops" at the hydraulic cylinders. This is to ensure smooth operation of the machine when reaching the hydraulic cylinder end stop.

Sensors involved


- Angle sensor at drawbar 70 Deg. Connected to JobCom
- Angle sensor rear under machine 120 Deg. Fitted at junction box under machine
- Boom fold sensor at boom swivel Connected to hydraulic harness
- Lock sensor under machine Connected at junction box under machine
- Speed sensor Connected to section valve PCB

Constants involved

- Speed
- Track With
- Chassis size
- Drawbar length
- Tractor drawbar length
- Calibration of proportional hydraulics
- Minimum radius
- Safety Factor
- Maximum speed

Pinning/plugs/colors/codes:

	Pot. meter	Sensor	AMP pin	PCB
Blue	Signal	Signal	3	-
Black	GND	GND	1	Signal
Brown	+12V	+12V	2	+



Fault finding options/results

Check power supply and hydraulic supply; follow instructions in Operators Instruction Book.

Measurements

- In menu 4.7 sensor readouts can be seen.
- Be careful as all automatic functions are disabled.
- Do not try to operate before checking that the boom is clear from the transport brackets and the SafeTrack lock under the machine is open.
- When machine are straight the potentiometers must show 2.5 Volt
- Inductive sensors show 0.8 V or 5.0 V

LookAhead

General info/description

LookAhead is a system which ensures the pressure regulation motor to be in the correct position even though the nozzles are not spraying. If the flow is under the minimum limit for the flow meter it changes to pressure based regulation if a pressure transducer is fitted.

PTO revolutions must be constant when using LookAhead. Calibration must be done at the same R.P.M. as when spraying.

To indicate the system is active, pressure regulation winds down and up during start up. System is disabled when boom is folded.

Sensors involved

Speed sensor

Flow sensor

Pressure regulation position sensor

Boom unfold sensor

Pressure transducer if fitted

Constants involved

SpeedPWM (Ext menu)

FlowReg. constant (Ext menu)

Boom sections/width

Check flow meter calibration

Diameter 13mm ca. 120 PPUOne outside groove

Diameter 20mm ca. 60 PPUNo groove

Diameter 36mm ca. 17 PPUTwo outside grooves

Pinning/plugs/colors/codes

Pressure regulation valve

Function	Positions		Color
SGND	-	J2	Black
SIG	Reg fb	J2	Blue
+12V sensor	+	J2	Brown
+12V power	Reg +	J3	Brown
GND	Reg -	J3	Blue

Fault finding options/results

Measurements

Pressure regulation valve

Peak load Max 0.6 amp.

Normal load Max 0.4 amp

Signal is Hz.

Pressure based regulation

General info/description

To improve non equal pressure systems such as EFC, PrimeFlow, EVC with closed equal pressure ports, is it as an option possible to equip the system to switch from flow to pressure based regulation. The system switch automatically when the flow drops below the minimum flow rate selected in the controller.

The drop of flow can be due to how many sections are selected for the boom and how many nozzles there are in each section. If there are few or only one nozzle in the last section of the boom and the sprayer is spraying in a angle and only the last section is open there is almost no flow in the liquid system and it will close down.

It will be the same if the sprayer is fitted with a large flow house, then the flow meter will measure almost no flow with small boom sections or nozzles with low output (L/min).

With the sensor installed the liquid system will switch to pressure based regulation instead.

To switch from flow to pressure based regulation a pressure sensor needs to be installed. The sensor is mounted in the liquid system on the boom and connected to the PCB in the distribution valve junction box on the rear of the sprayer.

For mounting and setup of the sensor please read the "Sensor" chapter in this book, page 74.

Boot sequence

When the pressure sensor is active will the HC6500 prompt for a nozzle choice. The last used nozzle is designated by the % symbol at the line of the nozzle description in the display.


If the nozzle and application rate used at last spray job is going to be re-used, then press ~ and the work screen will appear.

If not; select another nozzle and press # and the minimum pressure screen will appear.

1.6 LookAhead nozzle select		
o »	1.6.06	Blue ISO 03
	1.6.07	Red ISO 04
	1.6.08	Brown ISO 05
	1.6.09	Grey ISO 06
	1.6.10	White ISO 08
	1.6.11	Light blue ISO 10
	1.6.12	Light green ISO 15
	1.6.13	Custom 1
	1.6.14	Custom 2
Select nozzle for ISO 03 for 1,2 l/min. at 3 bar		

Minimum pressure

In menu E8.1.3 is the minimum allowed pressure typed in. In practice, this means the regulation will stop if the pressure goes below this value.



The screenshot shows a control interface with a boom icon at the top. Below the boom, the text reads "E8.1.3 Minimum pressure" followed by a large "0.5" and "Bar" below it. At the bottom, a note states "Pressure where regulation valve starts. Needs a pressure sensor".

AutoFill

General info/description

When AutoFill is started the agitation will automatically go to no agitation.
 If the "0 agitation" key is pressed for 2 sec, the AutoAgitation will be disabled.
 AutoAgitation then has to be setup in menu 2.2.6
 If rinse tank is not completely full, the system will show "Rinse tank not full" when filling is completed.

Sensors involved

- Potentiometer inside motor housing of suction valve
- Main tank full sensor
- Tank content sensor (Tank Gauge)
- Rinse tank full sensor
- Agitation position sensor

Constants involved

- Tank gauge calibration

Pinning/plugs/colors/codes


Electrical filling valve:

Function	Positions		Color
SGND	-	J1	Black
SIG	Fill. val. fb	J1	Blue
+12V sensor	+	J1	Brown
+12V power	Filler +	J3	Brown
GND	Filler -	J3	Blue

Tank gauge sensor:

Function	Positions		Color
SGND	-	J1	Black
SIG (Hz)	Tank gauge	J1	Blue
+12V sensor	+	J1	Brown

Cable is connection to potentiometer:




Fault finding options/results

Electrical filling valve
 When 12 Volt is applied to the brown wire and ground to the blue wire, the valve will turn clockwise when looking through the threaded connecting opposite the motor housing


Measurements

Menu 4.5.4.5 motor suction valve
 Open to suction smart valve at 0.5 V
 Closed 1.8 V



Tank full sensors Main & Rinse tank

The tank full sensors in the tanks read:
 "OL" ohm for open
 1.0ohm for closed
 Connection at J1 to Jobcom ver. 2.1



Headland Assist

General info/description

A potentiometer on PARALIFT measures boom height. A potentiometer on pendulum will measure slant angle. The system will lift the boom when turning at headland and can be set to mirror slant angle at the same time.

At startup or when folding, the system enters manual mode (state 1, ON or OFF). The system remains in this state until the nozzles are opened. When the nozzles are opened, it enters state 2. From this state the user can either enter AUTO ON (state 3) or MANUAL OFF (state 1). If the pendulum is locked, an alarm is displayed when spraying is commenced.

If the boom is operated manually while HeadlandAssist is in the process of moving it, the system immediately jumps to MANUAL mode.

Sensors involved

Potentiometer on PARALIFT120 Deg. connected to hydraulic harness

Potentiometer on Pendulum30 Deg. connected to JobCom J2

Speed sensor

Constants involved

Delay from tractor (reference point) to boom on sprayer

Height to raise boom when turning

Speed constant

Pinning/plugs/colors/codes

FunctionPositionsColor

SGND-J2Black

SIGheightJ2Blue

+12V sensor+J2Brown

Fault finding options/results


Check that boom reacts correctly to control box buttons (manual), up/down and slant right/left.

Measurements

Check menu 4.5.4.4

Turn slant potentiometer to the sprayers' right side, reading is 3.6 to 4V.

Turn height potentiometer to the up, reading is 3.6 to 4V.



	State	State icon	Nozzle icon
1	When folded it is assumed that the sprayer has just arrived in the field and therefore has not or has just been powered up (booted).		
2	After unfolding the boom no spraying height has yet been recorded and AUTO mode isn't possible yet.		
3	When the nozzles are opened for the first time the system changes from MANUAL OFF to MANUAL ON. The boom height is already or is now in the process of being adjusted by the operator.		
4	Now AUTO at the HeadlandAssist icon can be pressed. Manual control of the boom is still possible at this point.		
5	In the event of an obstacle – known or suddenly appearing – the set delay can be overridden by a long press on the OFF button.		
6	After clearing the obstacle the boom is readjusted, the operator presses ON and starts moving. As the machine is in MANUAL the nozzles open immediately.		
7	Now AUTO is pressed and spraying continues normally.		
8	When pressing OFF HeadlandAssist is activated. The machine continues with normal pressure regulation through the predefined delay.		
9	When the HeadlandAssist delay has been travelled, the nozzles close, the spraying height and slant angle is registered and the boom is lifted and the slant is centred as simultaneously as possible. From the moment the nozzles close, LookAhead takes over the positioning of the regulation valve.	 	

10	When pressing ON the lowering of the boom and the mirroring of the slant angle is initiated as simultaneously as possible. The distance driven starts counting up to the set HeadlandAssist delay. LookAhead still controls pressure regulation.		
11	When the HeadlandAssist delay is driven the nozzles are opened. Until the regulation delay has expired, LookAhead controls the regulation valve.		
12	If OFF is pressed by accident and it is detected by the operator before the HeadlandAssist delay has expired.....		
13the operator can press ON and spraying is resumed without incident. The driven distance under the HeadlandAssist delay must be reset so the nozzles don't close to soon next time OFF is pressed.		
14	During spraying the operator can adjust boom height and slant angle. This doesn't affect the AUTO mode.		
15	After pressing OFF and before the nozzles close the operator adjusts boom height and slant angle. This doesn't affect the AUTO mode as the boom height and slant angle are not registered until at step 16 when the nozzles close.		
17	During turning in the headland the operator adjusts boom height and slant angle. This doesn't affect the AUTO mode. Likewise the operator can stop the sprayer to take a break without interfering with the AUTO mode.		
18	When pressing ON the boom is moved to the last registered spraying height. The slant angle of the boom in step 16 is used to calculate the new slant angle regardless of the corrections made in step 17.		
22	If ON is pressed unintentionally, the boom will begin moving to the last registered spraying height and mirror the last registered slant angle immediately.		
23	Before the expiry of the HeadlandAssist delay OFF is pressed which causes the system to stop the boom immediately and return to MANUAL mode with the nozzles closed. An audible and visual alarm is given to the operator.		
24	The nozzles are opened by pressing ON. As the system is in MANUAL mode, the nozzles open immediately. LookAhead controls the regulation valve until the expiry of the regulation delay. After pressing ON the operator can switch to AUTO mode.		
26.	At the end of the last tramline the sprayer is stopped which causes the system to enter MANUAL mode. OFF is pressed and the nozzles close immediately. The operator manoeuvres the sprayer to the end of the headland in order to spray this last part of the field.		
27.	The operator lowers the boom manually, presses ON and commences forward driving.		
28.	When the operator stops at the far end of the headland no warning is given as the system was in MANUAL mode.		

STATE 1 to 4 when spraying					
STATE #	1	2	3	3b	4
ICONS DISPLAYED					
ACTION TAKEN	HeadlandAssist MANUEL NOZZLES OFF	HeadlandAssist MANUEL NOZZLES ON	HeadlandAssist AUTO NOZZLES ON	FINISH BOOM MOVEMENT AUTO ON	WAIT DELAY
NO INPUT	No action.	No action.	No action.	Open nozzles. Finish boom movement. Goto state #3.	When delay is expired, read spraying height and slant angle. Close nozzles. Goto state #5.
PRESS ON/OFF	Goto state #2.	Goto State #1.	Goto state #4.	Stop boom movement. Goto state #4.	Reset delay. Goto state #3.
PRESS AUTO	ILLEGAL! No action.	Goto state #3.	Goto state #2.	Goto state #2.	Goto state #2.
MANUEL CONTROL OF LIFT OR SLANT	Move boom accordingly.	Move boom accordingly.	Move boom accordingly.	WARNING! Move boom accordingly. Goto state #2.	Move boom accordingly.
LONG PRESS ON/OFF	Goto state #2.	Goto state #1.	Goto state #1.	Stop boom movement. Goto state #1.	Goto state #1.
SLOW DOWN BELOW LIMIT	No action.	No action.	Goto state #2.	Goto state #2.	WARNING! Goto state #2.
FOLD BOOM	Move boom accordingly.	Move boom accordingly.	Move boom accordingly. Goto state #2.	WARNING! Move boom accordingly. Goto state #2.	WARNING! Move boom accordingly. Goto state #2.
OPERATE SMARTVALVES	Move valves accordingly.	Move valves accordingly.	Move valves accordingly. Goto state #2.	Move valves accordingly. Goto state #2.	Move valves accordingly. Goto state #2.
CENTER SLANT	Move boom accordingly 	Move boom accordingly 	Move boom accordingly 	WARNING! Goto state #2	Move boom accordingly 
STATE 5 to 8 in headland					
STATE #	5	6	7	8	
ICONS DISPLAYED					
ACTION TAKEN	MOVE BOOM TO TURNING HEIGHT	MOVE BOOM TO SPRAYING HEIGHT	WAIT REMAINING DELAY	AUTO OFF	
NO INPUT	When desired height is reached and slant is centered goto state #8.	If delay expires goto state #3b. When desired spraying height and slant angle is reached goto state #7.	When delay is expired open nozzles. Goto state #3.	No action.	
PRESS ON/OFF	WARNING! Goto state #1.	WARNING! Goto state #1.	WARNING! Goto state #1.	Goto state #6.	
PRESS AUTO	Stop boom movement. Goto state #1.	Stop boom movement. Goto state #1.	Goto state #1.	Goto state #1.	
MANUEL CONTROL OF LIFT OR SLANT	WARNING! Move boom accordingly. Goto state #1.	WARNING! Move boom accordingly. Goto state #1.	Move boom accordingly.	Move boom accordingly.	
LONG PRESS ON/OFF	Stop boom movement. Goto state #1.	Stop boom movement. Goto state #1.	Goto state #1.	Goto state #1.	
SLOW DOWN BELOW LIMIT	No action.	No action.	No action.	No action.	
FOLD BOOM	WARNING! Move boom accordingly. Goto state #1.	WARNING! Move boom accordingly. Goto state #1.	WARNING! Move boom accordingly. Goto state #1.	Move boom accordingly. Goto state #1.	
OPERATE SMARTVALVES	Move valves accordingly. Goto state #1.				
CENTER SLANT	WARNING! Goto state #2	WARNING! Goto state #2	Move boom accordingly 	Move boom accordingly 	

AutoWash

General info/description

Wash programmes are started with the F soft keys in the right side of the display.
 Manual pressure +/- can be used during wash in case pressure is too high or too low.
 In case a manual function has to be done by the operator this is shown in the display. Confirm that action has been taken with the F keys.
 Alarms (information level) can be neutralized by pressing enter and wash will continue.
 When programme is completed this is prompted in the display.

Sensors involved


- Suction smart valve potentiometer
- Pressure smart valve potentiometer
- Rinse tank flow meter
- Rinse tank full sensor
- Pressure regulation position sensor
- Agitation pressure regulation position sensor
- Tank content sensor (tank gauge)

Constants involved

- Rinse tank flow constant

Pinning/plugs/colors/codes

Cable is connected to potentiometer as shown:



Fault finding options/results

Check rinse tank content.
 Flow out of nozzles must be 30 l/min., raise pressure manually in case it is lower then this.


Measurements

The indicator and symbol on the valve has to line up when washing. If valves doesn't line up then check valve potion in menu 4.5.4.5


0 to 5 volt range of the slider corresponds to 340 degrees; note that the blind spot occupies 20 degrees. Hence 14.7 mV corresponds to 1 degree.

Minimum	Slider Voltage Nominal	Maximum	Pressure Smart Valve	AutoFill valve	Suction SmartValve NCM32-44	Suction SmartValve NCM6600
0,35	0,51	0,65	Pressure Empty	Fill open	Blind	MainTank
1,7	1,84	2	Sections	Fill closed	FastFiller	RinseTank
3	3,16	3,3	TankClean	(not used)	MainTank	Blind
4,35	4,49	4,65	Ejector	(Position not used)	RinseTank	FastFiller

Pressure smart valve.



Suction smart valve.



Wash program

There are 3 wash programmes

The following diagrams are showing which valves are active in the different steps in the washing programs.

When message "Start double pump" is shown, the hydraulic lever for the double pump must be activated and the "F button" done must be pressed. When prompted to stop the double pump, the oil flow is stopped by the hydraulic outlet and the "F button" are used to confirm that the action is taken.

BoomFlush

Suction Valve	Pressure Valve	Main ON/OFF	Cyklone Filter Boost	Agitation
---------------	----------------	-------------	----------------------	-----------

	Suction Valve	Pressure Valve	Main ON/OFF	Cyklone Filter Boost	Agitation
01					
02					
03					
04					
05					
06					
07					
08					
09					

Multi Rinse						Suction Valve	Pressure Valve	Main ON/OFF	Cyklone Filter Boost	Agitation
01	01									
02	02									
03	03									
04	04									
05	05									
06	06									
07	07									
08	08									
09	09									
10	10									
11	11					Double Pump Step				
12	12									
13	13									
14	14									
15	15									
16	20	24	28	32	36					
17	21	25	29	33	37					
18	22	26	30	34	38	Double Pump Step				
19	23	27	31	35	39					


TWIN

General info/description

The system has electrical actuators for fan speed and air/nozzle angle.
 Two preset combinations of speed and position can be stored in 1 and 2.
 They can be chosen on the Setbox or on the 2 buttons on the front of the Grip.
 Sensors involved
 TWIN fan speed sensor in blower housing
 Constants involved
 R/min. PPU for fan

Pinning/plugs/colors/codes

Color	Harness plug	Actuator plug	Function
White	2	1	PGND
Brown	1	2	SGND
Green	3	3	+12V
Yellow	4	4	SIG
Angle L / R and fan speed has the same color combinations of wires			



Disconnection options/results

If actuators are moving unintended, disconnect the 2 fuses placed in the middle of the JobCom PCB.
 Do not unplug the actuators at the AMP plugs (on boom), as spray liquid may corrode the AMP plugs causing internal short-circuits.


Measurements

Disconnect the yellow wire for TWIN fan speed, right or left side actuators and measure the Voltage. Must be 0 V. If not so, then this there are short-circuits in the actuators or harness.
 Note! All other wires must be connected.

AutoAgitation

General info/description

The schematics show the standard setting from the factory. The curve can be moved back and forth but the syntax can not be changed.



AutoAgitation will stop when FastFiller is used but start up again when AutoFill is stopped or ended. Long key press on "0 Agitation" on FluidBox will turn off agitation completely. If agitation is turned off, it can be started by in menu 2.2.6 AutoAgitation.

Sensors involved

- Tank Gauge
- Agitation pressure regulation position sensor

Constants involved

- Tank gauge calibration

Pinning/plugs/colors/codes

- Agitation pressure regulation valve

Function	Position	Connector	Color
SGND	-	J2	Black
SIG	Agt fb	J2	Blue
+12V sensor	+	J2	Brown
+12V power	Agt +	J3	Brown
GND	Agt -	J3	Blue

Fault finding options/results

- Tank gauge must function correctly.
- The procedure for testing the agitation motor is the same as the pressure regulation motor as they are identical.

Measurements

- Agitation level can be selected to be shown in the display

PrimeFlow


PrimeFlow system:

- General description of the electronic, page 48
 - Cable configuration
 - Jobcom
 - Central junction box
 - SMCU
 - Stepper motor
- Basic setup of PrimeFlow, page 51
- Test of complete PrimeFlow, page 53
- Nozzle positions test, page 54
- Programming a new SMCU, page 56
- Reset a single SMCU, page 60
- Change SMCU 3 motor to 2 motor drive, page 60

Fault finding:


- PrimeFlow fault finding; check first guide, page 63
- How to fault find when the programming did not succeed, page 64
- Alarm 99, data cable weakness, page 66
- Alarm 100, Low PrimeFlow voltage, page 69
- Warning 101 PrimeFlow power cable defect, page 70
- Warning 102 PrimeFlow computer defect, page 70
- Checking SMCU and stepper motors, page 71


General description of the electronic:



1. HC6500
2. JobCom junction box
3. Cable JobCom to Junction box, P/N 26015000
4. Cable Junction to SMCU
5. Central junction box
- 6A. SMCU, number 1
- 6X. SMCU, number x from left side of boom
7. Stepper motor

Cable configuration






1	White	GND
2	Brown	BUS +
3	Green	+24Vcc
4	Yellow	Bus -

Jobcom

JobCom with Power PCB



Power PCB



P/N 26016400


If PrimeFlow is fitted, a power PCB for the PrimeFlow mounted in the Jobcom.

The power PCB has to step-up the 12 Volt from the battery to 24 Volt so the central junction box will work optimal.

There are 2 fuses:
 30AT F2 / 32V 311
 10AT F1 / 32V 313 (Hardi ref. no. 26023500)

Central junction box

The central junction box PCB, P/N 26027000 is mounted on the centre part of the boom.
 It is not possible to make any adjustments on this PCB.
 Wires can be checked for short circuit.
 If there is a short circuit on the left or right side of the boom the two fuses (10A) will be damaged.
 If there is an error in the PrimeFlow system and the alarm will start it can be switch-off by flipping the switch inside the gray box.
 Normal position is down. If the switch is up It will allow the farmer to continue spraying with out any alarms.



Color	Connection
Yellow	BUS -
Blue	Vcc
Brown	BUS +
White	Gnd

SMCU

The SMCU is the device that is controlling the stepper motor, each SMCU has to be programmed to a exact position on the boom and a exact order the stepper motor should turn on or off compared to each other.
 When the system is setup correctly, the stepper motor -nozzle, farthest to left on the boom will open first in the "Test Nozzle positions" test in menu E8.6.4.2, then nozzle next on the right side will open.
 The menu E8.6.4.2 setup PrimeFlow SMCU and nozzle numbers in each SMCU module and it makes JobCom register what SMCU and nozzle numbers is mounted on the boom.

Setup nozzle position can operate in 2 ways:

"1 beep way": Reconfirm SMCU and nozzle numbers. JobCom updates data on SMCU. No data is programmed in the SMCU.

"2 or 3 beep way": Position on boom is programmed in SMCU. JobCom updates data on SMCU.

There are two types of SMCU, one that can control 2 step motors and one that can control 3 step motors.

A 3 step motor type can be programmed to control 2 step motors, use menu E8.6.4.4 "Force to 2 motor drive" to change to 2 motor drive.

LED is light at all time: SMCU is reset to factory setting. They have no address so Jobcom can not open and close them.

LED is flashing (slow or fast): SMCU is programmed to a place on the boom.


LED is flashing slow: 1 Hz all nozzles are closed.

LED is flashing fast: 4 Hz 1 or more nozzles are open.

When programming the SMCU should the power supply only be connected from the left side of the boom.


When resetting a single SMCU should all other SMCU be disconnected from the data bus.

LED codes on SMCU



Stepper motor



8 L/min. max. With 1 bar pressure drop
 0.5 sec reaction time
 Grease between O-rings



PrimeFlow basic setup

PrimeFlow is setup in menu E8.6.4.2 "Assign nozzle position to SMCU" and E8.6.4.6 "Change Nozzle order".
 If a master reset made for other reason e.g. software update has been done a "Assign nozzle position" setup in menu E8.6.4.2 has to be performed.
 The master reset clears the information stored i JobCom about the connected PrimeFlow SMCU's. When performing confirmation of already programmed PrimeFlow SMCU's this data is recreated in the JobCom.

<p>Confirmation of already programmed PrimeFlow SMCU's is made with all cables mounted. The PrimeFlow SMCU's do not need to be powered up one at a time Check that all PrimeFlow SMCU's LED either blinks or is lit up constantly.</p>	<p>A: Left outer, connected B: Left inner, connected C: Right inner, connected D: Right outer, connected</p>														
<p>Terminal show: Menu E8.6.4 PrimeFlow setup Choose Menu E8.6.4.2 Assign nozzle positions to SMCU</p>	<table border="1"> <tr> <td colspan="2">E8.6.4 PrimeFlow setup</td> </tr> <tr> <td>E8.6.4.1</td> <td>Test Nozzle positions</td> </tr> <tr> <td>» E8.6.4.2</td> <td>Assign nozzle position to SMCU</td> </tr> <tr> <td>E8.6.4.3</td> <td>Reset nozzle position in SMCU</td> </tr> <tr> <td>E8.6.4.4</td> <td>Force to 2 motor drive</td> </tr> <tr> <td>E8.6.4.5</td> <td>Reserved</td> </tr> <tr> <td>E8.6.4.6</td> <td>Change Nozzle order</td> </tr> </table> <p>Assign nozzle position after replacement Confirm nozzle position after master reset</p>	E8.6.4 PrimeFlow setup		E8.6.4.1	Test Nozzle positions	» E8.6.4.2	Assign nozzle position to SMCU	E8.6.4.3	Reset nozzle position in SMCU	E8.6.4.4	Force to 2 motor drive	E8.6.4.5	Reserved	E8.6.4.6	Change Nozzle order
E8.6.4 PrimeFlow setup															
E8.6.4.1	Test Nozzle positions														
» E8.6.4.2	Assign nozzle position to SMCU														
E8.6.4.3	Reset nozzle position in SMCU														
E8.6.4.4	Force to 2 motor drive														
E8.6.4.5	Reserved														
E8.6.4.6	Change Nozzle order														
<p>Terminal show: Menu E8.6.4.2.1 Prepare cables for assign pos Press enter to start confirmation</p>	<p>E8.6.4.2.1 Prepare cables for assign pos</p> <p>0</p> <p>Connect SMCU having nozzle position. Disconnect reset SMCU. Then press enter</p>														



<p>Terminal show: Menu E8.6.4.2.2 SMCU nozzle position assigned. Terminal counts up number for confirmed nozzles and gives a single beep for each PrimeFlow SMCU</p>	 <p>The terminal display shows a status bar with 'auto' (checked), 'Track', a battery icon, a padlock icon, and '01'. Below this is a diagram of a boom with 6 triangles representing nozzles. The text 'E8.6.4.2.2 SMCU nozzle position assigned' is displayed above the number '6'. At the bottom, it says 'When counter stops, check position, then connect'.</p>
<p>When terminal stops counting Check that number of nozzles shown on terminal equals number of nozzles on boom Press enter to finish and return</p> <p>24m boom: Stop at 48 36m boom: Stop at 72</p>	 <p>The terminal display shows the same status bar as above. The diagram of the boom now has 21 triangles. The text 'E8.6.4.2.2 SMCU nozzle position assigned' is displayed above the number '21'. At the bottom, it says 'When counter stops, check position, then connect'.</p>

Test PrimeFlow setup



Test of complete system

<p>Check that all sections are open.</p> <p>Switches on Grip points downwards.</p>	
<p>Start pump</p> <p>Start HC6500 in normal mode (not in extended menu)</p> <p>Press Main on off button to close sections (red frame triangles)</p>	
<p>Check that all SMCU LED's blink slowly 1Hz</p>	
<p>Press Main on off button to open sections (Green solid triangles)</p>	
<p>Check that all SMCU LED's blink fast 4Hz</p> <p>Adjust pressure to between 3 and 5 bar</p> <p>Close pressure regulation valve</p> <p>Close agitation, if flow is inadequate</p> <p>Check that all nozzles spray</p> <p>They must not be closed or drip</p>	
<p>Start HC6500 in normal mode (not in extended menu)</p> <p>Press Main on off button to close sections (red frame triangles)</p>	
<p>Check that all SMCU LED's blink slowly 1Hz</p> <p>Check that all nozzles are able to close i.e. do not spray or drip</p>	

Nozzle positions test


<p>Turn off HC6500 and start HC6500 in extended menu Select Menu E8 Setup Menu E8.6 Sprayer type liquid boom Menu E8.6.4 PrimeFlow setup</p>	<table border="1"> <tr> <td colspan="2">E8.6 Sprayer type, liquid, boom</td> </tr> <tr> <td>E8.6.1</td> <td>Liquid system</td> </tr> <tr> <td>E8.6.2</td> <td>Dual Line</td> </tr> <tr> <td>E8.6.3</td> <td>Boom hydraulics type</td> </tr> <tr> <td>» E8.6.4</td> <td>PrimeFlow setup</td> </tr> <tr> <td>E8.6.5</td> <td>AutoWash AutoFill setup</td> </tr> </table> <p>Setup and test SMCU's First select PrimeFlow in E8.6.1.3</p>	E8.6 Sprayer type, liquid, boom		E8.6.1	Liquid system	E8.6.2	Dual Line	E8.6.3	Boom hydraulics type	» E8.6.4	PrimeFlow setup	E8.6.5	AutoWash AutoFill setup		
E8.6 Sprayer type, liquid, boom															
E8.6.1	Liquid system														
E8.6.2	Dual Line														
E8.6.3	Boom hydraulics type														
» E8.6.4	PrimeFlow setup														
E8.6.5	AutoWash AutoFill setup														
<p>Menu E8.6.4.1 Test Nozzle positions When pressing enter next screen appear and test starts</p>	<table border="1"> <tr> <td colspan="2">E8.6.4 PrimeFlow setup</td> </tr> <tr> <td>» E8.6.4.1</td> <td>Test Nozzle positions</td> </tr> <tr> <td>E8.6.4.2</td> <td>Assign nozzle position to SMCU</td> </tr> <tr> <td>E8.6.4.3</td> <td>Reset nozzle position in SMCU</td> </tr> <tr> <td>E8.6.4.4</td> <td>Force to 2 motor drive</td> </tr> <tr> <td>E8.6.4.5</td> <td>Reserved</td> </tr> <tr> <td>E8.6.4.6</td> <td>Change Nozzle order</td> </tr> </table> <p>Each nozzle is closed for 2 sec. Check that sequence does not jump</p>	E8.6.4 PrimeFlow setup		» E8.6.4.1	Test Nozzle positions	E8.6.4.2	Assign nozzle position to SMCU	E8.6.4.3	Reset nozzle position in SMCU	E8.6.4.4	Force to 2 motor drive	E8.6.4.5	Reserved	E8.6.4.6	Change Nozzle order
E8.6.4 PrimeFlow setup															
» E8.6.4.1	Test Nozzle positions														
E8.6.4.2	Assign nozzle position to SMCU														
E8.6.4.3	Reset nozzle position in SMCU														
E8.6.4.4	Force to 2 motor drive														
E8.6.4.5	Reserved														
E8.6.4.6	Change Nozzle order														
<p>Menu E8.6.4.1.1 Test Nozzle positions Each nozzle is closed for 2 sec. Check that sequence does not jump</p> <p>Note fault in help text: Each nozzle is opened for 2 sec</p> <p>Test sequence is started</p>	 <p>Each nozzle is closed for 2 sec.</p>														
<p>Immediately = After 0 seconds Display show 0 All nozzles are open, display show green solid triangles</p>															
<p>All nozzles are open</p>	<p>All nozzles open, all LED's blink 4Hz</p> 														

<p>After 5 seconds Display show 0 All nozzles are closed, display show red frame triangles</p>	
<p>All nozzles are closed</p>	<p>LED's blink 1Hz LED's blink 1Hz</p>
<p>After 8 seconds Display show 0 All nozzles are open, display show green solid triangles</p>	
<p>All nozzles are open</p>	<p>All nozzles open, all LED's blink 4Hz</p>
<p>After 11 seconds Display show 0 All nozzles are closed, display show red frame triangles</p>	
<p>All nozzles are closed</p>	<p>LED's blink 1Hz LED's blink 1Hz</p>
<p>One nozzle is opened at a time A: Left boom side Nozzle 1 sprays for 2 seconds Nozzle 2 sprays for 2 seconds</p>	





<p>Display show positive number when the nozzle just opened has a short cable being the SMCU's first nozzle</p> <p>Display show negative number when the nozzle just opened has a medium or long cable being the SMCU's 2nd or 3rd nozzle</p> <p>Negative is medium or long. Nozzle 3 spray for 2 seconds.</p>	 <p>E8.6.4.1.1</p> <p style="font-size: 2em; text-align: center;">3</p> <p>Each nozzle is closed for 2 sec.</p>
<p>A: Left boom side</p> <p>Nozzle 3 sprays for 2 seconds</p> <p>Nozzle 4 sprays for 2 seconds</p>	






Programming a new SMCU

Before a new SMCU can be used in the PrimeFlow system it has to be programmed with a nozzle position, therefore perform following procedure when you receive a new SMCU from Hardi.

<p>Check that the spare part SMCU is reset</p> <p>Connect the new PrimeFlow SMCU to any connector, ex. at the connector on the left outer boom side.</p> <p>Check that LED turns on and that it does not blink</p> <p>LED on others SMCU should blink If it blinks, it is currently has assigned a nozzle position and cannot be assigned a new position.</p> <p>Take an other SMCU, check that this is reset If impossible, the SMCU must be reset, see next section and be careful</p>	
--	---






<p>Disconnect the connectors Right Outer boom side. Disconnect extension cable</p> <p>A: Left outer, connected B: Left inner, connected C: Right inner, connected D: Right outer, dis-connected</p>															
<p>Delta boom Right outer cables Disconnect cable to SMCU from cable to PrimeFlow junction box</p>															
<p>Force boom Right outer cables Disconnect cable to SMCU from cable to PrimeFlow junction box</p> <p>Note: Photo from front side of sprayer</p>															
<p>Clip the new spare part PrimeFlow SMCU on to the boom tube Note: Do not yet connect any of the 2 pcs. 4 pole AMP plugs for Prime-Flow bus</p>															
<p>Select Menu E8.6.4.2 Assign nozzle position to SMCU Assign nozzle position after replacement Confirm nozzle position after master reset</p> <p>"Assign nozzle position" does not require a master reset of JobCom. Master reset of JobCom requires as Assign nozzle position. (Master reset made for other reason e.g. software update) See "Confirm already programmed PrimeFlow SMCU's"</p>	<table border="1"> <tr> <td colspan="2">E8.6.4 PrimeFlow setup</td> </tr> <tr> <td>E8.6.4.1</td> <td>Test Nozzle positions</td> </tr> <tr> <td>» E8.6.4.2</td> <td>Assign nozzle position to SMCU</td> </tr> <tr> <td>E8.6.4.3</td> <td>Reset nozzle position in SMCU</td> </tr> <tr> <td>E8.6.4.4</td> <td>Force to 2 motor drive</td> </tr> <tr> <td>E8.6.4.5</td> <td>Reserved</td> </tr> <tr> <td>E8.6.4.6</td> <td>Change Nozzle order</td> </tr> </table> <p>Assign nozzle position after replacement Confirm nozzle position after master reset</p>	E8.6.4 PrimeFlow setup		E8.6.4.1	Test Nozzle positions	» E8.6.4.2	Assign nozzle position to SMCU	E8.6.4.3	Reset nozzle position in SMCU	E8.6.4.4	Force to 2 motor drive	E8.6.4.5	Reserved	E8.6.4.6	Change Nozzle order
E8.6.4 PrimeFlow setup															
E8.6.4.1	Test Nozzle positions														
» E8.6.4.2	Assign nozzle position to SMCU														
E8.6.4.3	Reset nozzle position in SMCU														
E8.6.4.4	Force to 2 motor drive														
E8.6.4.5	Reserved														
E8.6.4.6	Change Nozzle order														





<p>Menu E8.6.4.2.1 Prepare cables for assign pos Connect SMCU having nozzle position Disconnect reset SMCU. Then press enter</p> <p>Cabling is just connected as specified in help text. Press enter</p>	 <p>E8.6.4.2.1 Prepare cables for assign pos</p> <p>0</p> <p>Connect SMCU having nozzle position. Disconnect reset SMCU. Then press enter</p>
<p>After mounting the last PrimeFlow SMCU, check that the terminal display counter show the number of nozzles on the boom.</p>	
<p>Menu E8.6.4.2.2 SMCU nozzle position assigned When counter stops, check position, then connect next SMCU. Press enter at finish</p> <p>Check that display counts up until the PrimeFlow SMCU to be replaced. Check that terminal for each existing SMCU gives 1 beep, which means that existing SMCU ID is correct.</p>	 <p>E8.6.4.2.2 SMCU nozzle position assigned</p> <p>6</p> <p>When counter stops, check position, then connect</p>
<p>Picture shows cables before they are connected and before SMCU is assigned nozzle position</p>	
<p>When the terminal stops counting and beeping, then Connect the cable with the 4 poles AMP connector to the new PrimeFlow SMCU Check that the PrimeFlow SMCU LED blinks</p>	











<p>Determine whether the new PrimeFlow SMCU is for 2 motors (nozzles) or 3 motors (nozzles) When it is a 2 motor SMCU: Check that terminal gives 2 beeps Check that terminal display increases counter by 2.</p> <p>When it is a 3 motor SMCU: Check that terminal gives 3 beeps Check that terminal display increases counter by 3 Now the new PrimeFlow SMCU is programmed</p>	 <p>E8.6.4.2.2 SMCU nozzle position assigned 9</p> <p>When counter stops, check position, then connect</p>
<p>The Terminal stops counting and beeping Connect the cable with the 4 pole AMP from the new PrimeFlow SMCU to the next existing PrimeFlow SMCU</p>	 <p>Connect cable from new SMCU to next SMCU</p>
<p>Check that display continues to count. Check that terminal for each existing SMCU gives 1 beep, which means that existing SMCU ID is correct.</p>	 <p>E8.6.4.2.2 SMCU nozzle position assigned 12</p> <p>When counter stops, check position, then connect</p>
<p>When the Terminal stops counting and beeping, check that the terminal display counter show the number of nozzles on the boom.</p> <p>24m boom: Stop at 48 36m boom: Stop at 72</p>	 <p>E8.6.4.2.2 SMCU nozzle position assigned 21</p> <p>When counter stops, check position, then</p>
<p>Right Outer boom side. Connect extension cable Now all 4pcs. 4 pole AMP connector are connected again.</p> <p>A: Left outer, connected B: Left inner, connected C: Right inner, connected D: Right outer, connected</p>	
<p>Perform boom test and single nozzle test to verify replacement succeeded</p>	

Reset a single SMCU


First PrimeFlow power and databus is checked, to ensure that reset commends sent from JobCom will reach the SMCU to be reset. Change SMCU 3 motor to 2 motor drive

<p>Check that all sections are open (switches on Grip point downwards)</p>	
<p>Press Main on off button to open sections (Green solid triangles)</p>	
<p>Check that all SMCU LED's blink fast 4Hz except defect ones</p>	<p>All nozzles open, all LED's blink 4Hz</p> 
<p>Press Main on off button to close sections (red frame triangles)</p>	
<p>Check that all SMCU LED's blink slowly 1Hz except defect ones</p>	<p>LED's blink 1Hz LED's blink 1Hz</p> 
<p>Disconnect the connectors</p> <p>A: Left Outer. Disconnect connectors on SMCU. B: Left Inner. Disconnect extension cable C: Right Inner. Disconnect connectors on SMCU. D: Right Outer. Disconnect extension cable</p>	
<p>Check that all LED's are off Connect the new SMCU to the cable at Left Outer boom side</p> <p>1. Connect left outer to new SMCU.</p> <p>LED must be off on OK SMCU's.</p>	

<p>E8.6.4.3 Reset nozzle position in SMCU Resets all connected SMCU's to prepare for assignment of new nozzle position</p>	<p>E8.6.4 PrimeFlow setup</p> <ul style="list-style-type: none"> E8.6.4.1 Test Nozzle positions E8.6.4.2 Assign nozzle position to SMCU » E8.6.4.3 Reset nozzle position in SMCU E8.6.4.4 Force to 2 motor drive E8.6.4.5 Reserved E8.6.4.6 Change Nozzle order <p>Resets all connected SMCU's to prepare for assignment of new nozzle position</p>
<p>Press enter 2 previous photos of boom show disconnected SMCU' s as required in help text</p>	 <p>E8.6.4.3.1 Confirm reset of SMCU's</p> <p style="text-align: center; font-size: 2em;">0</p> <p>Connect SMCU at left side to reset.</p>
<p>Check that PrimeFlow SMCU LED lights constantly. SMCU is reset. HC6500 display counts up. Press ESC when SMCU's LED lights constantly</p>	 <p>E8.6.4.3.2 Resetting SMCU</p> <p style="text-align: center; font-size: 2em;">3</p> <p>SMCU's are reset. JobCom verifies each</p>
<p>Check that all LED's are off Connect the new SMCU to the cable at Left Outer boom side</p> <p>1. Connect left outer to new SMCU</p> <p>LED must be off on OK SMCU's</p> <p>LED change from blinks to constant light</p>	
<p>Order of operation: 1.Reset SMCU 2.Change to 2 motor drive as shown below 3.program nozzle number into SMCU</p> <p>A: Left outer, dis-connected B: Left inner, dis-connected C: Right inner, dis-connected D: Right outer, dis-connected</p>	

<p>The SMCU must be reset before a 3 motor SMCU is changed to 2 motor drive</p> <p>1. Connect left outer to new SMCU</p> <p>LED must be off on OK SMCU's</p> <p>LED change from blinks to constant light</p>															
	<table border="1" style="width: 100%;"> <tr> <td colspan="2">E8.6.4 PrimeFlow setup</td> </tr> <tr> <td>E8.6.4.1</td> <td>Test Nozzle positions</td> </tr> <tr> <td>E8.6.4.2</td> <td>Assign nozzle position to SMCU</td> </tr> <tr> <td>E8.6.4.3</td> <td>Reset nozzle position in SMCU</td> </tr> <tr> <td>» E8.6.4.4</td> <td>Force to 2 motor drive</td> </tr> <tr> <td>E8.6.4.5</td> <td>Reserved</td> </tr> <tr> <td>E8.6.4.6</td> <td>Change Nozzle order</td> </tr> </table> <p>For service a 3 motor SMCU can be forced to be a 2 motor drive</p>	E8.6.4 PrimeFlow setup		E8.6.4.1	Test Nozzle positions	E8.6.4.2	Assign nozzle position to SMCU	E8.6.4.3	Reset nozzle position in SMCU	» E8.6.4.4	Force to 2 motor drive	E8.6.4.5	Reserved	E8.6.4.6	Change Nozzle order
E8.6.4 PrimeFlow setup															
E8.6.4.1	Test Nozzle positions														
E8.6.4.2	Assign nozzle position to SMCU														
E8.6.4.3	Reset nozzle position in SMCU														
» E8.6.4.4	Force to 2 motor drive														
E8.6.4.5	Reserved														
E8.6.4.6	Change Nozzle order														
	<table border="1" style="width: 100%;"> <tr> <td style="text-align: center;">  </td> </tr> <tr> <td style="text-align: center;">E8.6.4.4.1</td> </tr> <tr> <td style="text-align: center;">0</td> </tr> <tr> <td>Connect motor</td> </tr> </table>		E8.6.4.4.1	0	Connect motor										
															
E8.6.4.4.1															
0															
Connect motor															
	<table border="1" style="width: 100%;"> <tr> <td style="text-align: center;">  </td> </tr> <tr> <td style="text-align: center;">E8.6.4.4.2</td> </tr> <tr> <td style="text-align: center;">0</td> </tr> <tr> <td>In progress!</td> </tr> </table>		E8.6.4.4.2	0	In progress!										
															
E8.6.4.4.2															
0															
In progress!															
<p>Error message</p>	<table border="1" style="width: 100%;"> <tr> <td style="text-align: center;">  </td> </tr> <tr> <td style="text-align: center;">E8.6.4.4.4</td> </tr> <tr> <td style="text-align: center;">0</td> </tr> <tr> <td>System cannot program SMCU</td> </tr> </table>		E8.6.4.4.4	0	System cannot program SMCU										
															
E8.6.4.4.4															
0															
System cannot program SMCU															

PrimeFlow fault finding; check first guide



- A: HC6500
- B: JobCom
- C: Central junction box at the centre part of the boom; data com and 24V connection to SMCU
- D: Left boom
- E: Right boom

Caution:

All PrimeFlow cables have to be connected and the Data com switch (S1) on the central junction PCB has to be in down position. If the S1 has changed position is it necessary to turn ON/OFF the controller.

A: General fault finding

1. Check fuse on PrimeFlow PCB in the JobCom
2. Check PrimeFlow fuses 10A (F1, F2), in the junction box PCB on the centre part of the boom
3. The data com switch (S1) should be set in the Down position, Full Duplex
4. All SMCU LED should flash, if not there is no 24V, continue fault finding at point C.1
5. Enter Menu 4.5.3; check the SMCU for data and/or power errors
6. Enter Menu 4.5.6; Reset SMCU error counters
7. If possible turn the nozzles on/off 5-6 times
8. Enter Menu 4.5.3 again and check the error log
9. Replace defect SMCU

B: Data com fault finding

1. Disconnect cable on last SMCU at the right boom
2. Use Menu E8.6.4.2 to assign nozzle position to SMCU
3. If possible for all nozzles, turn the controller ON/OFF, see if the fault still are there
4. If only possible for some nozzles, it may be a SMCU or connector at the right side of the SMCU where the process stopped that is defect
5. If it is not possible to assign nozzle position; Disconnect SMCU from right to left until assign of nozzles is possible. Last disconnected cable or SMCU is defect, replace this SMCU.
6. In menu E8.6.4.1 check that all nozzles open in the right order

C: Power fault

1. Disconnect cable from last SMCU on right boom. If the LED not is flashing on all SMCU's there is a power failure on the right side of the boom with the SMCU that is flashing
2. Replace the defect SMCU, check that there is no error code and proceed to point 3
3. Disconnect cable from last SMCU on left boom. If the LED not is flashing on all SMCU's there is a power failure on the right side of the boom with the SMCU that is flashing
4. Replace the defect SMCU; check that there is no error code

PrimeFlow cable configuration			PrimeFlow error log	
Connector	Conductor	Signal	Error code	Error
Pin 1	White	GND = 0 Volt	99	Flow data cable weakness
Pin 2	Brown	Data-bus +	100	Low PrimeFlow voltage
Pin 3	Green	Vcc = 24 Volt	101	PrimeFlow power cable defect
Pin 4	Yellow	Data-bus -	102	PrimeFlow computer defect

Fault finding options and results




How to fault find when the programming did not succeed


<p>When connecting a SMCU for assigning nozzle position and no beep sounded then 2 SMCU's can be defect: Either the last SMCU - which could not be assigned - already had a nozzle position - or the SMCU just before, which can have a defect data cable</p> <ol style="list-style-type: none"> 1. SMCU 1 is ok 2. SMCU 2 is ok 3. SMCU 3 beeps ok. Perhaps defect 4. SMCU 4 gives no beep. Perhaps defect 	
<p>Verify that counter on terminal</p>	
<p>show the position of the last = right-most nozzle which connected and assigned to an SMCU</p>	

If positions does not match, something else went wrong.
 Reset the complete boom, disconnect all connectors and begin programming them from left side again.

If position match, check cables from previous SMCU.

Measure between pin 1 and pin x; expected values:					
PIN	Color	Function	VDC	VAC	Unit
1	White	GND	0	0	V
2	Brown	Data bus +			V
3	Green	Vcc	24		V
4	Yellow	Data bus -			V

<p>Inside limits then continue:</p>															
<p>If measurements are inside limits, then the fault is in the last SMCU, which could not be assigned a nozzle position. simply take a new SMCU and continue programming</p> <ol style="list-style-type: none"> 1. SMCU 1 is ok 2. SMCU 2 is ok 3. SMCU 3 Measurements inside limits 4. SMCU 4 is defect 															
<p>Outside limits then replace previous</p>															
<p>If one (or several) of the 3 cables gives measurements outside the limits, then the previous SMCU is defect Because the fault SMCU was assigned a nozzle position correctly, programming must be stopped and started again.</p> <ol style="list-style-type: none"> 1. SMCU 1 is ok 2. SMCU 2 is ok 3. SMCU 3 beeps ok, but cable to next is defect 4. SMCU 4 gives no beep, but is not defect 															
<p>Disconnect and dismount this SMCU and report it defect Do not disconnect other cables</p> <p>Stop programming by pressing ESC</p> <p>Start programming again Select Menu E8.6.4.2 Assign nozzle position to SMCU Assign nozzle position after replacement, Confirm nozzle position after master reset</p>	<table border="1" style="width: 100%;"> <tr> <td colspan="2">E8.6.4 PrimeFlow setup</td> </tr> <tr> <td>E8.6.4.1</td> <td>Test Nozzle positions</td> </tr> <tr> <td>» E8.6.4.2</td> <td>Assign nozzle position to SMCU</td> </tr> <tr> <td>E8.6.4.3</td> <td>Reset nozzle position in SMCU</td> </tr> <tr> <td>E8.6.4.4</td> <td>Force to 2 motor drive</td> </tr> <tr> <td>E8.6.4.5</td> <td>Reserved</td> </tr> <tr> <td>E8.6.4.6</td> <td>Change Nozzle order</td> </tr> </table> <p>Assign nozzle position after replacement Confirm nozzle position after master reset</p>	E8.6.4 PrimeFlow setup		E8.6.4.1	Test Nozzle positions	» E8.6.4.2	Assign nozzle position to SMCU	E8.6.4.3	Reset nozzle position in SMCU	E8.6.4.4	Force to 2 motor drive	E8.6.4.5	Reserved	E8.6.4.6	Change Nozzle order
E8.6.4 PrimeFlow setup															
E8.6.4.1	Test Nozzle positions														
» E8.6.4.2	Assign nozzle position to SMCU														
E8.6.4.3	Reset nozzle position in SMCU														
E8.6.4.4	Force to 2 motor drive														
E8.6.4.5	Reserved														
E8.6.4.6	Change Nozzle order														
<p>Menu E8.6.4.2.1 Prepare cables for assign pos Connect SMCU having nozzle position Disconnect reset SMCU. Then press enter</p> <p>Cabling is just connected as specified in help text. Press enter</p>	 <p>E8.6.4.2.1 Prepare cables for assign pos</p> <p style="text-align: center; font-size: 2em;">0</p> <p>Connect SMCU having nozzle position. Disconnect reset SMCU. Then press enter</p>														

<p>Menu E8.6.4.2.2 SMCU nozzle position assigned Counter will increase until the last signed nozzle where it will stop counting It will give 1 beep at each count</p>	 <p>E8.6.4.2.2 SMCU nozzle position assigned</p> <p style="text-align: center; font-size: 2em;">6</p> <p>When counter stops, check position, then</p>
---	---

PrimeFlow alarms

Alarm 99, data cable weakness


Test 1A:

Turn on the HC6500

Measure the voltage between following points on the PrimeFlow Junction box PCB L-OUTER terminal J2:

If voltage on Bus+ and Bus- are above values specially if voltage is above 5 volt, a SMCU's has a fault between VCC (24V) and the bus wires.

Then none of the RS485 modules can work




Terminal	Terminal	Max value	Unit	Min. value	Unit
GND	Vcc	28	V	23	V
GND	L-Outer Bus-	2,5	V	2,2	V
GND	L-outer Bus+	2,7	V	2,5	V
Bus+	Bus-	5,2	V	4,7	V


Check of 37 pole cable from JobCom to PrimeFlow junction box
 Move switch lever up to Half Duplex position.
 Turn off and turn on HC6500

If Alarm 99 still occurs with this setting (Half Duplex position)
 1) 37 pole cable from JobCom to PrimeFlow junction box is faulty
 2) Short circuit PrimeFlow junction box, cables and SMCU's on the boom.
 Continue with test 1 and then 2

If Alarm 99 does not occurs now (disappears), the fault is isolated to a disconnection in the PrimeFlow junction box, cables and SMCU's on the boom
 Move switch lever down to Full Duplex position again



Check of data cables and SMCU's on the boom
 Turn off HC6500
 Wait until the supercaps has discharged. LED's on PrimeFlow SMCU's are off. (Alternatively remove the to red 10A fuses)
 Measure resistance between screw/cable-terminals as described.
 Note that in most cases all cables should be connected in the terminals.
 Resistances in JobCom and SMCU's are included in specified limits.
 A note specifies when a wire should be dismantled.



Test 1: Test disconnection of data cables on boom:

In terminals	In terminals	Max limit	Min. limit	Write value
L-Outer Bus+	R-Outer Bus+	5 ohm	1 ohm	
L-Outer Bus-	R-Outer Bus-	5 ohm	1 ohm	

If above max limit continue with test 4a, 4b, 4c, 4d.

Test 2: Test short circuit of data cables

In terminals	In terminals	Max limit	Min. limit	Write value
L-Outer Bus+	L-Outer Bus-	160 ohm	140 ohm	

2 pcs termination resistors in the JobCom makes 150 ohm
 Disconnection in PrimeFlow data cables will increase to 300 ohm or more, also tested in Test 1
 Resistance below Min. limit indicates short circuit between Bus+ and Bus-.
 Go to Test 5 to identify location of short circuit

Test 3: Test short circuit to GND and Vcc (24V)

In terminals	In terminals	Max limit	Min. limit	Write value
L-Outer Gnd	L-Outer Bus+		290 ohm	
L-Outer Gnd	L-Outer Bus-		290 ohm	
L-Outer Vcc	L-Outer Bus+		1 Mohm	
L-Outer Vcc	L-Outer Bus-		1 Mohm	

If values are below Min. limit, use Test 5 to identify location of short circuit

Test 4A: Find boom part of disconnection

In terminals	In terminals	Max limit	Min. limit	Write value
L-Inner Bus+	R-Inner Bus+	3 ohm	1 ohm	
L-Inner Bus-	R-Inner Bus-	3 ohm	1 ohm	

If values are above Max limit, fault is on the PrimeFlow junction box PCB

In terminals	In terminals	Max limit	Min. limit	Write value
L-Outer Bus+	L-Inner Bus+	4 ohm	1 ohm	
L-Outer Bus-	L-Inner Bus-	4 ohm	1 ohm	

If values are above Max limit, fault is on the left boom part, use Test 4c to identify location

In terminals	In terminals	Max limit	Min. limit	Write value
R-Inner Bus+	R-Outer Bus+	4 ohm	1 ohm	
R-Inner Bus-	R-Outer Bus-	4 ohm	1 ohm	

If values are above Max limit, fault is on the right boom part, use Test 4c to identify location

Test 4B: Find SMCU position of disconnection on left boom part

Dismount the 4 wires mentioned in the table and measure between the wires ends

Dismounted	Dismounted	Max limit	Min. limit	Write value
L-Outer Bus+	L-Outer Bus-			
L-Inner Bus+	L-Inner Bus-			

Compare with values in test 4D

Test 4C: Find SMCU position of disconnection on right boom part

Dismount the 4 wires mentioned in the table and measure between the wires ends

Dismounted	Dismounted	Max limit	Min. limit	Write value
L-Outer Bus+	L-Outer Bus-			
L-Inner Bus+	L-Inner Bus-			

Compare with values in test 4D

Test 4D: Measure and count position of disconnection.

Resistance	Disconnection between:
>1MOhm	Junction box and SMCU 1
260 kOhm	SMCU 1 and 2
130 kOhm	SMCU 2 and 3
87 kOhm	SMCU 3 and 4
65 kOhm	SMCU 4 and 5
52 kOhm	SMCU 5 and 6
43 kOhm	SMCU 6 and 7
37 kOhm	SMCU 7 and 8
33 kOhm	SMCU 8 and 9
29 kOhm	SMCU 9 and 10
26 kOhm	SMCU 10 and 11
24 kOhm	SMCU 11 and 12
22 kOhm	SMCU 12 and 13
20 kOhm	SMCU 13 and 14
19 kOhm	SMCU 14 and 15
17 kOhm	SMCU 15 and 16
16 kOhm	SMCU 16 and 17
15 kOhm	SMCU 17 and 18
14 kOhm	SMCU 18 and 19

Each SMCU includes a resistor of 260 kOhm between Bus+ and Bus-.

Hence all connected SMCU's add 160 kOhm in parallel.

The higher the number of SMCU's connected, the lower the resistance measured.

Resistance measured between Outer Bus wires defines a SMCU position counted from the outer end of the boom wing.

Resistance measured between Inner Bus wires defines a SMCU position counted from the inner end of the boom wing.

Test 4E: Use 2 adaptor cables with AMP connectors to measure resistance between connectors at the ends of cables and SMCU's to check location of fault.

Test 5: Find boom part with short circuit

Dismount the 4 Inner Bus wires and measure between

The wires L-Outer Gnd and L-Outer Vcc can stay in terminals

Dismounted	Dismounted	Max limit	Min. limit	Write value
L-Inner Bus+	L-Inner Bus-		140 ohm	

If the value is below Min. limit, fault is on left boom part

In terminals	Dismounted	Max limit	Min. limit	Write value
L-Outer Gnd	L-Inner Bus+		140 ohm	
L-Outer Gnd	L-Inner Bus-		140 ohm	
L-Outer Vcc	L-Inner Bus+		1 Mohm	
L-Outer Vcc	L-Inner Bus-		1 Mohm	

If the value is below Min. limit, fault is on left boom part

Dismounted	Dismounted	Max limit	Min. limit	Write value
R-Inner Bus+	R-Inner Bus-		140 ohm	

If the value is below Min. limit, fault is on right boom part

In terminals	Dismounted	Max limit	Min. limit	Write value
L-Outer Gnd	R-Inner Bus+		140 ohm	
L-Outer Gnd	R-Inner Bus-		140 ohm	
L-Outer Vcc	R-Inner Bus+		1 Mohm	
L-Outer Vcc	R-Inner Bus-		1 Mohm	


If the value is below Min. limit, fault is on right boom part

Use Test 6 to identify location on boom part of short circuit

Test 6 to identify location on boom part of short circuit

Keep multimeter test leads mounted on the 2 terminals, which show the faults.

Divide boom in halves by opening 4 pole AMP connectors to narrow in location of short circuit




Alarm 100 Low PrimeFlow voltage

JobCom measure PrimeFlow supply voltage after fuse for left and right boom part at AI11 and AI12. Alarm occur when voltage is below 14 volts.

A fuse is open or too many rapid shifts on and off of sections has drained the power supply

Warning 101 PrimeFlow power cable defect

Low power warning from SMCU, when supply is re-established.
 First low power warning received after power up of system is not valid
 First low power warning received after "Low voltage on supercap" is not valid
 Poor power wiring to PrimeFlow computers. One of the 2 power lines are disconnected or connectors are corroded and gives high resistance
 Test: Find boom part with short circuit
 Dismount the Gnd, Vcc in the upper screw terminal blocks, which are easy accessible.



In terminals	Dismounted	Max limit	Min. limit	Write value
L-Inner Gnd	L-Outer Gnd	2 Ohm		
L-Inner Vcc	L-Outer Vcc	2 Ohm		
R-Inner Gnd	R-Outer Gnd	2 Ohm		
R-Inner Vcc	R-Outer Vcc	2 Ohm		

Warning 102 PrimeFlow computer defect

SMCU does not reply on status
 No status request while "Low voltage on supercap" occurs
 Internal fault in PrimeFlow computer. Can also be caused by 2 or more defects in PrimeFlow data cable. Check for PrimeFlow data cable weakness

<p>Menu 4.5.3 PrimeFlow test PrimeFlow test for nozzles and PrimeFlow computers on boom</p> <p>Check No answer count</p>	<p>4.5 Test</p> <ul style="list-style-type: none"> » 4.5.1 Flow Speed Optional sensors 4.5.2 Action keys 4.5.3 PrimeFlow test 4.5.4 Input test 4.5.5 Valve test <p>Activate function to monitor sensor (e.g. drive forwards, start flow)</p>
<p>Menu 5.2.2 Hyper terminal service report Open Service report in Notepad Check No answer count</p>	<pre> 9036 Jolin Hobbs Service Report 28-03-07 Notepad File Edit Format View Help HARDI HC6500 - PrimeFlow status ***** SMCU;Nozzle;2or3;Noz; Low pow; No answ Pos; 1st ID;noz; Swp; count; count 001; 001; 3; ---; 0001; 0004 002; 004; 3; ---; 0001; 0004 003; 007; 2; ---; 0001; 0004 004; 009; 3; ---; 0001; 0005 005; 012; 2; ---; 0001; 0005 006; 014; 2; ---; 0001; 0005 007; 016; 3; ---; 0001; 0005 008; 019; 3; ---; 0001; 0005 </pre>

Checking SMCU and stepper motors

4 types of fault are seen

SMCU motor driver transistor is defect

Stepper motor does not rotate

Stepper motor has lost power but can rotate

Valve seat is leaking

PrimeFlow Basic rules

Power connects to the boom centre.

Data/power connects to the boom ends.

When programming:

Always disconnect data cable at the right boom end.

Always start the programming at the left boom end.

Always disconnect power at the centre at the boom when resetting a SMCU.

If SMCU LED is flashing, it must be reset before it can be re-programmed.

Sensors

General info/description

Tank gauge
 Main and rinse tank full sensors
 Speed, TWIN, Boom and SafeTrack lock sensors
 Front angle sensor
 SafeTrack and Paralift angle sensor
 Slant angle sensor
 Flow
 Pressure sensor


Pinning/plugs/colors/codes

General:

	Angle sensor	Sensor	AMP Connector	PCB
Blue	Signal	Signal	3	Signal
Black	GND	GND	1	-
Brown	+12V	+12V	2	+


Tank gauge

Hardi P/N: 26014100
 Type: Pressure
 Range: 0-250mBar
 Signal: 100-2600Hz, open collector NPN
 Pull up: 10K Ohm to Vcc
 Power: 12V
 Hardi Pin assignment: Brown +
 Blue signal
 Black -




Tank full switch

Hardi P/N: 72411300
 Type: Switch
 Full tank: Switch open
 Not full tank: Switch closed, <2.0 ohm
 Power: 12V
 Hardi Pin Assignment: Brown +
 Blue signal
 Black -




Speed, TWIN, Boom and SafeTrack lock sensor

Hardi P/N 28047500
 Type: Inductive
 Range: 0-8mm
 Signal: 0-200Hz
 Operation indicator: Yellow light when active (0,8V)
 Power: 12V
 Visual indicator: LED to indicate active stastatus
 Hardi Pin assignment: Brown +
 Blue signal
 Black-




Front angle sensor:

Hardi P/N 26005700
 Type: Potentiometer
 Range: 0-70°
 Signal: 0,5 - 4,5V
 Centre position: 2,5 V
 Power: 12V
 Hardi Pin assignment: Brown +
 Blue signal
 Black -




SafeTrack and Paralift angle sensor:

Hardi P/N 26005800
 Type: Potentiometer
 Range: 0-120°
 Signal: 0,5 - 4,5V
 Centre position: 2,5 V
 Power: 12V
 Hardi Pin assignment: Brown +
 Blue signal
 Black -




Slant angle sensor:

Hardi P/N 26014300
 Type: Potentiometer
 Range: 0-30°
 Signal: 0,5 - 4,5V
 Centre position: 2,5 V
 Power: 12V
 Hardi Pin assignment: Brown +
 Blue signal
 Black -




Flow sensor:

Hardi P/N 72117500
 Type: Inductive
 Range: On, 0,2-0,5 V
 Off, 6,5-7,0 V
 Visual indicator: Red light when Off (0,8V)
 Power: 12V
 Hardi Pin assignment: Brown +
 Blue signal
 Black -




Pressure sensor:

Hardi P/N 842022
 Type: Pressure
 Range: 0-10 Bar
 Signal: 4-20mA
 Power supply: 8-30V
 Hardi pin assignment: Brown +
 Blue Signal
 Black N/C




Pressure sensor connection:


9 Section PCB
 The wires from the Pressure sensor is connected to "Opt 1"
 on the 9 section PCB P/N 262108



13 Section PCB
 The wires from the Pressure sensor is connected to "Pressure"
 on the 13 section PCB P/N 26004800



PrimeFlow
 The wires from the Pressure sensor is connected to "Pressure"
 on the PrimeFlow PCB P/N 26027000



Sensor setup

The boom pressure sensor is setup in menu E8.1.7.

Default setting for the sensor is "passive".

If the sensor is set to passive it can only be used for read out purpose.

Select "active" when the sensor should be used for regulation at low flow.

E8.1.7.1 Pressure
» E8.1.7.11 Pressure sensor: Passive E8.1.7.12 Pressure sensor: Active
Pressure sensor used for read out purpose only

Display readout setup

For a readout on the HC6500, the sensor must be setup.

To show the pressure in the upper middle window select E.2.1.1.11.

2.1.1 Show upper middle
E2.1.1.07 Speed E2.1.1.08 Volume sprayed E2.1.1.09 Area sprayed E2.1.1.10 Active boom size o » E2.1.1.11 Pressure E2.1.1.12 Fan speed E2.1.1.13 Wind speed E2.1.1.14 Wind direction E2.1.1.15 Humidity
Displays spray pressure if sensor is fitted

Alarms:

Alarm 109; pressure sensor:

The alarm is generated, if the sensor signal is shorted or not connected.

The HC6500 has min. and max pressure alarm that can be shown in the display.

The display need to be set up to show this alarm.

Cable from Jobcom to tractor



General info/description

The cable from Jobcom to tractor has 7 wires and the connector is a standard 13 pin M / F following the ISO 11446.

See section COMMUNICATION / CAN for wire connection on Jobcom.

Consult Operators Instruction book for connections to tractor battery

Pinning/plugs/colors/codes



Revision

P/N 679096-201		Service Manual HC6500		Revision 2.01. GB 10.2008	
Date	Revision	Subject	Section	Pages	Author
13-03-2007	1.8	Release of manual	All	25	AF
14-03-2008	2.00	Menu tree, Datacom and PrimeFlow fault finding added	Ext menu, datacom and PrimeFlow	57	PAO
07-10-2008	2.01	Updated	Menu tree, Datacom, PrimeFlow faultfinding, Sensors.	5-10,13-31, 61-69,70-73	PAO
		Added	Pressure regulation, PrimeFlow description, setup, test, programming. Software error codes	34, 46-60. 25-26	PAO
		Removed	Guidance for HC6500 setup	(4)	PAO